



# Network Appliance Platform

Hardware Platforms for Network Computing

## NCA-6040 User Manual

Version: 1.7

Date of Release: 2024-07-02

## About this Document



This manual describes the overview of the various functionalities of this product, and the information you need to get it ready for operation. It is intended for those who are:

- responsible for installing, administering and troubleshooting this system or Information Technology professionals.
- assumed to be qualified in the servicing of computer equipment, such as professional system integrators, or service personnel and technicians.

The latest version of this document can be found on Lanner's official website, available either through the product page or through the [Lanner Download Center](#) page with a login account and password.

## Icon Description

The icons are used in the manual to serve as an indication of interest topics or important messages.

Icon	Usage
 <b>Note or Information</b>	This mark indicates that there is something you should pay special attention to while using the product.
 <b>Warning or Important</b>	This mark indicates that there is a caution or warning and it is something that could damage your property or product.

## Online Resources

To obtain additional documentation resources and software updates for your system, please visit the [Lanner Download Center](#). As certain categories of documents are only available to users who are logged in, please be registered for a Lanner Account at <http://www.lannerinc.com/> to access published documents and downloadable resources.

## Technical Support

In addition to contacting your distributor or sales representative, you could submit a request at our [Lanner Technical Support](#) and fill in a support ticket to our technical support department.

## Documentation Feedback

Your feedback is valuable to us, as it will help us continue to provide you with more accurate and relevant documentation. To provide any feedback, comments or to report an error, please email [contact@lannerinc.com](mailto:contact@lannerinc.com). Thank you for your time.

## Copyright and Trademarks

This document is copyrighted © 2024 by Lanner Electronics Inc. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

## Contact Information

### Taiwan Corporate Headquarters

**Lanner Electronics Inc.**

7F, No.173, Sec.2, Datong Rd.  
Xizhi District, New Taipei City 22184,  
Taiwan

**立端科技股份有限公司**

221 新北市汐止區  
大同路二段 173 號 7 樓  
T: +886-2-8692-6060  
F: +886-2-8692-6101  
E: [contact@lannerinc.com](mailto:contact@lannerinc.com)

### USA

**Lanner Electronics Inc.**

47790 Westinghouse Drive  
Fremont, CA 94539  
T: +1-855-852-6637  
F: +1-510-979-0689  
E: [sales\\_us@lannerinc.com](mailto:sales_us@lannerinc.com)

### Europe

**Lanner Europe B.V.**

Wilhelmina van Pruysenweg 104  
2595 AN The Hague  
The Netherlands  
T: +31 70 701 3256  
E: [sales\\_eu@lannerinc.com](mailto:sales_eu@lannerinc.com)

### China

**Beijing L&S Lancom Platform Tech. Co., Ltd.**

Guodong LOFT 9 Layer No. 9 Huinan Road,  
Huilongguan Town, Changping District, Beijing  
102208 China  
T: +86 010-82795600  
F: +86 010-62963250  
E: [service@ls-china.com.cn](mailto:service@ls-china.com.cn)

### Canada

**Lanner Electronics Canada Ltd**

3160A Orlando Drive  
Mississauga, ON  
L4V 1R5 Canada  
T: +1 877-813-2132  
F: +1 905-362-2369  
E: [sales\\_ca@lannerinc.com](mailto:sales_ca@lannerinc.com)

## Acknowledgment

Intel® and Intel® Celeron® are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

### FCC Caution

- ▶ Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- ▶ This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



#### Note

1. An unshielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



#### Important

1. Operations in the 5.15-5.25GHz band are restricted to indoor usage only.
2. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.



## Safety Guidelines

Follow these guidelines to ensure general safety:

- ▶ Keep the chassis area clear and dust-free during and after installation.
- ▶ Do not wear loose clothing or jewelry that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- ▶ Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- ▶ Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- ▶ Disconnect all power by turning off the power and unplugging the power cord before installing or removing a chassis or working near power supplies
- ▶ Do not work alone if potentially hazardous conditions exist.
- ▶ Never assume that power is disconnected from a circuit; always check the circuit.

## Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- ▶ Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- ▶ Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- ▶ Portez des lunettes de sécurité pour protéger vos yeux.
- ▶ N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
- ▶ Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- ▶ Ne travaillez pas seul si des conditions dangereuses sont présentes.
- ▶ Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

## Lithium Battery Caution

- ▶ There is risk of explosion if the battery is replaced by an incorrect type.
- ▶ Dispose of used batteries according to the instructions.
- ▶ Installation should be conducted only by a trained electrician or only by an electrically trained person who knows all installation procedures and device specifications which are to be applied.
- ▶ Do not carry the handle of power supplies when moving to another place.
- ▶ Please conform to your local laws and regulations regarding safe disposal of lithium battery.
- ▶ Disposing of a battery in fire, a hot oven, or cutting/crushing it mechanically can cause an explosion.
- ▶ Leaving a battery in extreme heat can cause explosions or leaks of flammable substances.
- ▶ Exposing a battery to very low air pressure can cause explosions or leaks of flammable substances.

## Avertissement concernant la pile au lithium

- ▶ Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- ▶ Jetez les piles usagées conformément aux instructions.
- ▶ L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- ▶ Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.

## Operating Safety

- ▶ Electrical equipment generates heat. Ambient air temperature may not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Be sure that the room in which you choose to operate your system has adequate air circulation.
- ▶ Ensure that the chassis cover is secure. The chassis design allows cooling air to circulate effectively. An open chassis permits air leaks, which may interrupt and redirect the flow of cooling air from internal components.
- ▶ Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures. Be sure to follow ESD-prevention procedures when removing and replacing components to avoid these problems.
- ▶ Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. If no wrist strap is available, ground yourself by touching the metal part of the chassis.
- ▶ Periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohms).

## Sécurité de fonctionnement

- ▶ L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.
- ▶ Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- ▶ Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.
- ▶ Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.
- ▶ Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

## Mounting Installation Precautions

The following should be put into consideration for rack-mount or similar mounting installations:

- ▶ Do not install and/or operate this unit in any place that flammable objects are stored or used in.
- ▶ The installation of this product must be performed by trained specialists; otherwise, a non-specialist might create the risk of the system's falling to the ground or other damages.
- ▶ Lanner Electronics Inc. shall not be held liable for any losses resulting from insufficient strength for supporting the system or use of inappropriate installation components.
- ▶ Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T<sub>ma</sub>) specified by the manufacturer.
- ▶ Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.
- ▶ Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- ▶ Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- ▶ Reliable Grounding - Reliable grounding of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).
- ▶ Instruction for the installation of the conductor to building earth by a skilled person.

## Electrical Safety Instructions


Before turning on the device, ground the grounding cable of the equipment. Proper grounding (grounding) is very important to protect the equipment against the harmful effects of external noise and to reduce the risk of electrocution in the event of a lightning strike. To uninstall the equipment, disconnect the ground wire after turning off the power. A ground wire (green-and-yellow) is required and the part connecting the conductor must be greater than 6 mm<sup>2</sup> or 8AWG.

## Consignes de sécurité électrique

- ▶ Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- ▶ Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- ▶ Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- ▶ Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 6 mm<sup>2</sup> ou 8 AWG.


## Grounding Procedure for This Device

- ▶ Connect the grounding cable to the ground.
- ▶ The protection device for the DC power source must provide 40A current.
- ▶ This protection device must be connected to the power source before DC power.



## Procédure de mise à la terre l'équipement

- ▶ Branchez le câble de mise à la terre à la terre.
- ▶ L'appareil de protection pour la source d'alimentation CC doit fournir 40A de courant.
- ▶ Cet appareil de protection doit être branché à la source d'alimentation avant l'alimentation CC.



### Warning

- ▶ This equipment must be grounded. The power cord for product should be connected to a socket-outlet with earthing connection.
- ▶ Product shall be used with Class 1 laser device modules.
- ▶ Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.
- ▶ The machine can only be used in a restricted access location and be installed and serviced by skilled person.

### Avertissement

- ▶ Cet équipement doit être mis à la terre. La fiche d'alimentation doit être connectée à une prise de terre correctement câblée
- ▶ Le produit doit être utilisé avec des modules de dispositifs laser de classe 1.
- ▶ Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.
- ▶ Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.

For DC input, this unit is intended to be supplied by an UL listed power source, rated 48V to 60Vdc, 40A min, 60A max, and an altitude operation 5000m min.



**CAUTION:** TO DISCONNECT POWER, REMOVE ALL POWER CORDS FROM UNIT.

注意：要断开电源，请将所有电源线从本机上拔下。

注意：要斷開電源，請將所有電源線從本機上拔下。

**WARNING:** Wenn Sie das Gerät zwecks Wartungsarbeiten vom Netz trennen müssen, müssen Sie beide Netzteile abnehmen.

**ATTENTION:** DÉBRANCHER TOUS LES CORDONS D'ALIMENTATION POUR DÉCONNECTER L'UNITÉ DU SECTEUR.

# Table of Contents

---

<b>Chapter 1: Product Overview .....</b>	<b>10</b>
Package Content.....	10
Ordering Information .....	10
Optional Accessories .....	10
System Specifications .....	11
Front Panel .....	12
Rear Panel.....	13
<b>Chapter 2: Motherboard Information .....</b>	<b>14</b>
Block Diagram.....	14
Internal Jumpers and Connectors .....	15
<b>Chapter 3: Hardware Setup .....</b>	<b>24</b>
Installing the CPU .....	25
Installing the System Memory.....	31
Installing TPM Module (Optional) .....	33
Installing IPMI Card.....	34
Installing M.2 SATA Storage (Optional).....	35
Installing M.2 SSD Storage (Optional) .....	36
Installing DPU Expansion Card (Optional) .....	38
Installing the Disk Drive(s) .....	41
Installing the NIC Modules .....	42
Replacing the Cooling Fans.....	43
Replacing the Power Supply Units .....	44
Mounting the System .....	45

<b>Chapter 4: Remote Server Management (SKU A/SKU B) .....</b>	<b>50</b>
BMC Main Features .....	50
Firmware Functional Description .....	51
IPMI Commands Support List .....	53
Using BMC Web UI .....	55
<b>Chapter 5: BIOS Setup .....</b>	<b>61</b>
Main Page .....	62
Advanced Setup .....	63
Platform Setup .....	80
Socket Configuration .....	86
Server Mgmt (SKU A / SKU B) .....	95
Server Mgmt (SKU C) .....	97
Security Setup .....	102
Boot Setup .....	105
Save and Exit Setup .....	106
<b>Appendix A: LED Indicator Explanations .....</b>	<b>108</b>
<b>Appendix B: Dual BIOS Introduction .....</b>	<b>109</b>
<b>Appendix C: Redundant Power Module Behavior .....</b>	<b>111</b>
<b>Appendix D: Fan Sequence .....</b>	<b>112</b>
<b>Appendix E: Smart Power &amp; Reset Button .....</b>	<b>113</b>
<b>Appendix F: ESD/Surge Enhancement .....</b>	<b>114</b>
<b>Appendix G: Terms and Conditions .....</b>	<b>115</b>

# CHAPTER 1: PRODUCT OVERVIEW

The NCA-6040's specifications and outstanding features deliver maximized packet processing efficiency for virtual network functions, cryptography acceleration (for deep packet inspection) and next-generation firewall and UTM/IPS/IDS.

## Package Content

Your package contains the following items:

- ▶ 1x Network Security Platform
- ▶ 1x CPU Heatsink, 2x Processor Carrier (1x E1A for XCC CPU Series, 1x E1B for MCC CPU Series)
- ▶ 1x Console Cable, 1x RJ45 LAN Cable, 1x RJ45 Cross-over LAN Cable
- ▶ 2x Power Supply Cables
- ▶ 1x Short Ear Rack Mount Kit with screws

## Ordering Information

SKU No.	Main Features
NCA-6040A	5th Gen Intel® Xeon® Scalable Processors, 350W CPU TDP, with BMC Support, 4x System Fans, 8x NCS2 or 4x N2S NIC Modules, Support for FHFL PCIe Card (Under 150W)
NCA-6040B	5th Gen Intel® Xeon® Scalable Processors, 205W CPU TDP, with BMC Support, 4x System Fans, 8x NCS2 or 4x N2S NIC Modules, Support for FHFL PCIe Card (Under 75W)
NCA-6040C	5th Gen Intel® Xeon® Scalable Processors, 350W CPU TDP, 4x System Fans, 8x NCS2 or 4x N2S NIC Modules, Support for FHFL PCIe Card (Under 150W)

## Optional Accessories

Model No.	Description
Riser Card Kit	Riser Card Kit for rear side PCIe expansion
NCS2-LCM6210A	A Character LCM Module with Keypad
IAC-TPM04A	TPM 2.0 Module
IAC-AST2600	IPMI (Intelligent Platform Management Interface) Card Module
AC Power Module	1300W AC Power Module Kit
DC Power Module	1600W DC Power Module Kit
Fan Kit	Swappable Fan Kit
Slide Rackmount Rail Kit	Slide Rackmount Rail Kit with screw accessories




**Note:** In the event of missing or damaged components, please contact your dealer immediately for assistance.

## System Specifications

<b>Form Factor</b>		2U 19" Rackmount
<b>Platform</b>	Processor Options	5th Gen Intel® Xeon® Scalable Processor (Codenamed Emerald Rapids)
	CPU Socket	1x LGA4677
	Chipset	Intel® Emmisburg PCH
	Security Acceleration	Intel® QuickAssist Technology
<b>BIOS</b>		AMI SPI Flash BIOS
<b>System Memory</b>	Technology	DDR5 5600MHz RDIMM
	Max. Capacity	768GB
	Socket	12x 288-pin DIMM
<b>Networking</b>	Ethernet Ports	2x 2.5GbE RJ45 w/ LEDs by Intel® i226-LM
	Bypass	N/A
	NIC Module Slot	8x NCS2 or 4x N2S NIC Module Slots
<b>LOM</b>	IO Interface	1x RJ45 LOM Port (via BMC Chip) (By SKU)
	OPMA slot	Yes, Support AST2600 IPMI Card (By SKU)
<b>I/O Interface</b>	Reset Button	1x Reset Button
	LED Indicators	Power/Status/Storage LED Indicators
	Power Button	1x ATX Power Switch
	Console Port	1x RJ45 Console Port;
	USB Port	2x USB 3.0 Ports
	Display Port Power Input	1x VGA Port via AST2600 IPMI Card (By SKU) AC Power Inlet on PSU
<b>Storage</b>	HDD/SSD Support	2x 3.5" or 2x 2.5" HDD/SSD Swappable Bays
	Onboard Slots	1x M.2 2280 B+M Key for SATA; 2x M.2 2280 M-Key for NVMe (PCIe)
<b>Expansion</b>	PCIe	1x PCI-E*8 FH/FL (Optional)
	mini-PCIe	N/A
<b>Miscellaneous</b>	Watchdog	YES
	Internal RTC with Li Battery	YES
	TPM	Support IAC-TPM04 (Optional)
<b>Cooling</b>	Processor	Passive CPU heat sink
	System	4x Swappable Smart Cooling Fans
<b>Environmental Parameters</b>	Temperature	0~40°C Operating -40~70°C Non-Operating
	Humidity (RH)	5~90% Operating 5~ 95% Non-Operating
<b>System Dimensions</b>	(WxDxH)	438 x 660 x 88 mm
	Weight	24 kg
<b>Package Dimensions</b>	(WxDxH)	827 x 588 x 303mm
	Weight	26 kg
<b>Power</b>	Type/Watts	2x 1300W CRPS AC PSU (Default); 2x 1600W CRPS AC PSU (By Request)
	Input	AC 100~240V @47~63Hz
<b>Approvals and Compliance</b>		RoHS, CE/FCC Class A, UKCA, UL

## Front Panel




No.	Description	
F1	Reset Button	Software reset
F2	LED Indicators	
F3	USB Ports	2x USB 3.0 Ports
F4	RJ45 Ports	
F5	HDD/SSD Tray	2x 3.5" or 2x 2.5" HDD/SSD Tray 
F6	NIC Module	8x NCS2 Slim Type or 4x N2S NIC module



**Note:** Please refer to Appendix A: LED Indicator Explanations for descriptions of the LED Indicators (including those on MGMT Port, IPMI Port, GbE, SFP+ Ports and HDD trays)



Rear Panel




No.	Description	
R1	Rear PCIe Expansion	1x PCIe expansion slot (Optional)
R2	Power Switch	1x Power Button
R3	Fans	4x Swappable Smart Fans
R4	Power Supply	2x 1300W Redundant (N+1 Design) PSU

# CHAPTER 2: MOTHERBOARD INFORMATION


## Block Diagram

The block diagram indicates how data flows among components on the motherboard. Please refer to the following figure for your motherboard's layout design.




## Internal Jumpers and Connectors


The pin headers on the motherboard are often associated with important functions. With the shunt (Jumper) pushed down on the designated pins (the pin numbers are printed on the circuit board, surrounding the pin header), certain feature can be enabled or disabled. While changing the jumpers, make sure your system is turned off.




**A**



**B**




**C**






**D**



**E**



## F

**JESPI1:** ESPI CS1# Flow (ESPI Mode)

Pin No.	Description
1-2	CS1# To BMC (Default)
2-3	CS1# To ESPI CONN

**JMERCVR1:** ME FW Update

Pin No.	Description
1-2	Normal (Default)
2-3	ME Force Update

**JCLRPAS1: Password Clear**

Pin No.	Description
1-2	Normal (Default)
2-3	Password Clear

**JDUAL1: Select CS for Flash Fixture**

Pin No.	Description
1-2, 3-4	Flash 1 <sup>st</sup> BIOS (Default)
1-3, 2-4	Flash 2 <sup>nd</sup> BIOS



**JFOR\_PWRON1:** Force PWRON Options

Pin No.	Description
1-2	Disable (Default)
2	Enable

**J13:** BIOS Boot Up Select

Pin No.	Description
1-2	Force Boot Up from BIOS1 (Default)
2-3	Force Boot Up from BIOS2

**J12:** Disable Dual BIOS Function

Pin No.	Description
1-2	Enable Dual BIOS (Default)
2-3	Disable Dual BIOS

**JP12V\_DIMM1:** P12V\_DIMM Status

Pin No.	Description
1-2	P12V_DIMM Off in S5 (Default)
2-3	P12V_DIMM on in S5

**JRST1:** Select Front Panel Reset

Pin No.	Description
1-2	Hardware Reset
2-3	Software Reset (Default)

**JBMC\_INIT1**

Pin No.	Description
1-2	N/A
2-3	Normal Boot Flow (Default)

**JCMOS1:** CMOS Clear

Pin No.	Description
1-2	Normal (Default)
2-3	Clear CMOS


**JBIOSRCVR1:** BIOS Recovery Mode

Pin No.	Description
1-2	Normal Mode (Default)
2-3	Recover BIOS



**JGP1: GPIO1 Conn**

Pin No.	Description	Pin No.	Description
1	GPO_B_1	2	GPI_B_1
3	GPO_B_2	4	GPI_B_2
5	GPO_B_3	6	GPI_B_3
7	GPO_B_4	8	GPI_B_4
9	GND	10	GND

**JATX11**

Pin No.	Description	Pin No.	Description
1	GND	2	+P12V
3	GND	4	+P12V
5	GND	6	+P12V
7	GND	8	+P12V
9	GND	10	+P12V

**JATX7**

Pin No.	Description	Pin No.	Description
1	GND	7	+P12VS_PCl_e_A
2	GND	8	+P12VS_PCl_e_A
3	GND	9	+P12VS_PCl_e_A
4	GND	10	+P12VS_PCl_e_A
5	GND	11	+P12VS_PCl_e_A
6	GND	12	+P3V3

**ATX1**

Pin No.	Description	Pin No.	Description
1	GND	2	+P12V_STBY_PSU
3	GND	4	+P5V
5	GND	6	+P12V
7	GND	8	+P12V
9	GND	10	+P12V
11	GND	12	+P12V
13	GND	14	+P12V
15	GND	16	+P12V
17	GND	18	+P12V
19	GND	20	+P12V
21	GND	22	+P3V3
23	GND	24	+P3V3



**JCOM1**

Pin No.	Description	Pin No.	Description
1	COM2_DCD#	2	COM2_DSR#
3	COM2_RX	4	COM2_RTS
5	COM2_TX	6	COM2_CTS#
7	COM2_DTR	8	COM2_RI#
9	GND	10	N/C

**JSPI\_TPM1**

Pin No.	Description	Pin No.	Description
1	SPI_HD1#	2	SPI_CS1#
3	SPI_CS0#	4	+P3V3_SPI_PCH_AUX
5	SPI_MISO_TPM	6	HEADER_SPI_PCH_IO3
7	KEY	8	SPI_CLK_TPM
9	GND	10	SPI_MOSI_TPM
11	IRQ_TPM_SPI#_R	12	N/C
13	SPI_TPM_CS0#	14	RST_PLTRST_PLD_B_N

**JLCM1**

Pin No.	Description
1	LCM_TX
2	LCM_RX
3	GND
4	+P5V

**JUSB1**

Pin No.	Description	Pin No.	Description
1	+P5V_USB2	2	+P5V_USB2
3	USB20_L_N0	4	USB20_L_N1
5	USB20_L_P0	6	USB20_L_P1
7	GND	8	GND
9	GND	10	GND

**JESPI80PORT1**

Pin No.	Description	Pin No.	Description
1	+P5V_USB2	2	+P5V_USB2
3	USB20_L_N0	4	USB20_L_N1
5	USB20_L_P0	6	USB20_L_P1
7	GND	8	GND
9	GND	10	GND

**JPMB1**

Pin No.	Description
1	+P3V3_AUX_PSU
2	N/C
3	FM_PS_EN_PSU_N
4	GND
5	PWRGD_PS_PWROK
6	PMBUS_CLK_PSU_R
7	PMBUS_DAT_PSU_R
8	PMBUS_ALERT#_R

**JVGA1**

Pin No.	Description	Pin No.	Description
1	DAC_RO	2	GND
3	DAC_GO	4	GND
5	DAC_BO	6	GND
7	HSYNC_O	8	N/C
9	VSYNC_O	10	GND
11	DDC_DATA	12	DDC_CLK

**JPLD1**

Pin No.	Description
1	+P3V3_AUX
2	JTAG_PLD_TDO
3	JTAG_PLD_TDI
4	JTAG_PLD_TMS
5	GND
6	JTAG_PLD_TCK

**JBMC\_SGPIO1**

Pin No.	Description
1	SGPIO_DEBUG_PLD_CLK
2	SGPIO_DEBUG_PLD_DOUT
3	SGPIO_DEBUG_PLD_DIN
4	SGPIO_DEBUG_PLD_LD_N
5	GND

**JIPMB1**

Pin No.	Description
1	SMB_IPMB_STBY_CMOS_ISO_SDA
2	GND
3	SMB_IPMB_STBY_CMOS_ISO_SCL
4	+P5V_AUX

**JATX1, JATX2, JATX3, JATX4, JATX5, JATX6**

Pin No.	Description	Pin No.	Description
1	GND	2	GND
3	+P3V3	4	+P12V

**JBMC\_UART1**

Pin No.	Description
1	+P3V3_AUX
2	BMC_UART5_RX
3	GND
4	BMC_UART5_TX

## CHAPTER 3: HARDWARE SETUP

To reduce the risk of personal injury, electric shock, or damage to the system, please remove all power connections to completely shut down the device. Also, please wear ESD protection gloves when conducting the steps in this chapter.

### Opening the Chassis

1. Loosen the two (2) thumb screws from the rear panel.



2. Gently pull the cover backwards slightly.



3. Lift the cover up to remove.





## Installing the CPU

Please note that the system delivered to you includes the heatsink and processor. This processor comes with a rather sophisticated design, therefore, the assembly of which must be handled with exclusive tools and extreme care by professionals.

Installing the processor onto the motherboard involves three stages:

1. Processor carrier assembly
2. Processor carrier assembly to heatsink.
3. System assembly PHM (Processor + Heat Sink Module) to motherboard


### Tools Required




Tool	Description
<b>T-30 Torx Bit®</b>	Set to 0.904 N.m. (or 8 in/lbf $\pm$ 10%) for tightening the nuts which fasten the PHM on the bolster plate. 
<b>ESD Protection</b> (ESD gloves, ESD-safe work surface, ESD-safe shoes, grounded wrist strap etc.)	During the entire assembly process, at least wear a pair of ESD gloves to avoid damaging or contaminating the electronic parts while enhancing your own safety. 



**Note:** The images of tools shown in this document are merely for reference; the actual tools you use might differ.

### Parts Explanation:

Item	Description
<b>Processor</b>	<p>Please avoid touching the gold fingers or package lands of the processor even if you are wearing ESD gloves.</p> 

<b>Heatsink (1U &amp; 2U)</b>	<p>When handling heatsink, always grip it along the axis of the fins of the heatsink to avoid fin damage. Fins or soldering of fins might be damaged by handling heatsink holding along the long side of the heatsink.</p>	
<b>Processor Carrier</b>		
<b>Processor Tray</b>		


## Processor Carrier Assembly

1. Place the processor carrier on top of the processor that is in the package tray aligning **Pin 1** marks on the processor carrier to **Pin 1** of the processor.


Note: Make sure that the keying feature tabs of the processor carrier are aligned to the slots in the processor properly. If not check that the correct processor carrier is being used.



2. Using both hands place the thumbs on the side of the carrier at the opposite end of the TIM brake lever. Push down on one side at a time slightly pressing in the outward motion until a snap sound is heard.




3. Check the two side snap latches on the carrier and verify that they have latched to the package. If not then press down on top of the side snap latches until they snap into place.




## Processor Carrier Assembly to Heatsink

1. If there is TIM (Thermal Interface Material) protective film on the base of heatsink, remove it.







2. Turn the heatsink over and set the Anti-Tilt wires to the locked position (outward position).




3. Align Pin 1 indicator of Processor carrier and corner cut out of Heatsink. If there are two corners cut out, either orientation is fine.



4. Place the heatsink ensure latching features on Processor carrier and heatsink are aligned during assembly.




5. Press heatsink down firmly to engage carrier latching features to the heatsink at four corners.






6. If carrier latching features do not latch the heatsink properly, engage each latching feature by pressing the heatsink at the unlatched corner. You may hear a clicking sound when latched.




## System Assembly PHM to Motherboard


1. Locate the processor placement on the motherboard. Hold finger grips on socket cover and squeeze in on the grip tabs. Then pull the cover up and off vertically to remove.




2. Set each anti-tilt wire to inward or unlocked position on the heatsink.




3. Lift up the PHM. Turn the PHM over to locate the **PIN1** corner on processor carrier and processor.




4. Then turn the PHM right side up. Line up the **PIN1** corner of the PHM to the bolster plate **PIN1** corner. Lower the PHM vertically down over the bolster plate studs.




5. Set all four Anti-Tilt wires into the locked position (outward position.)



6. Next is to tighten the nuts on the heatsink using a diagonal pattern tightening sequence. Diagonal sequence is regardless of starting point. Primary step is Second nut driven is in diagonally opposite corner to the First nut.




7. Tighten all nuts on heatsink using a torque driver with a T30 bit to 8 in-lbf  $\pm$  10%.



## Installing the System Memory

The motherboard supports DDR5 registered DIMM memory for heavy-duty operations. Please follow the steps below to install the DIMM memory modules. The CPU have 12 DIMM sockets (6 on each sides)




- Supported Capacities: 8/16/32/64 GB
- Maximum RAM: **768GB** (64GB per slot)

### DIMM Population Guidelines

Please do follow the memory module installation instructions to install the DIMM, and make sure the DIMM population guidelines are met:

- Each CPU requires at least 1 memory module to boot and run from.
- If you do not plan to fill up all the sockets with 20 memory modules, always start with the blue ones for optimal performance.
- Try to split the DIMMs evenly across the CPUs.
- Please use memory modules of the same capacity, speed and from the same manufacturer to avoid compatibility issues.






## DDR5 Only DIMM Configurations Diagram

DDR5	iMC3			iMC2			CPU	iMC0			iMC1			SPR							
Channel	Chan1 (7/H)	Chan0 (6/G)		Chan1 (5/F)	Chan0 (4/E)			Chan0 (0/A)	Chan1 (1/B)	Chan0 (2/C)	Chan1 (3/D)		SNC2	All2All	SNC4 (XCC only)	Hemi- Note9	Quad (XCC only) Note9	Mirror	SGX- Note#6	Interleaving- Note8	
Location	H0	G0	G1	F0	E0	E1		A1	A0	B0	C1	C0	D0								
1 DIMM									DDR5						Y						
					DDR5										Y						
									DDR5						Y						
2 DIMM		DDR5							DDR5					Y			Y			2	
					DDR5							DDR5		Y			Y			2	
4 DIMM		DDR5			DDR5				DDR5			DDR5		Y		Y	Y	Y		4	
6 DIMM		DDR5			DDR5	DDR5			DDR5			DDR5	DDR5	Y	Y					6	
	DDR5	DDR5				DDR5			DDR5		DDR5		Y	Y					6		
	DDR5			DDR5	DDR5				DDR5		DDR5	DDR5	Y	Y					6		
	DDR5	DDR5		DDR5				DDR5	DDR5			DDR5	Y	Y					6		
8 DIMM	DDR5	DDR5		DDR5	DDR5			DDR5	DDR5		DDR5	DDR5	Y		Y	Y	Y	Y	8		
12 DIMM	DDR5	DDR5	DDR5	DDR5	DDR5	DDR5		DDR5	DDR5	DDR5	DDR5	DDR5	Y		Y	Y	Y		8+4		


## Memory Module Installation Instructions

Please follow the steps below to install the DIMM memory modules.


1. Power off the system.
2. Pull open the DIMM slot latches.



3. Align the notch of the DIMM module with the socket key in the slot.




4. Insert the module into the slot until it is firmly seated.




## Installing TPM Module (Optional)

The system provides one slot for a TPM module card to provide hardware-based security related functions. Follow the steps below for installations.

1. Power off the system and open the chassis cover.
2. Locate the TPM connector pins on the motherboard.






3. Insert the TPM module pins with the connector pins, until the module card is firmly seated.



## Installing IPMI Card

The system provides one IPMI slot for remote monitoring expansion. Follow the procedure below for installation.

1. Power off the system and open the chassis cover.
2. Locate the IPMI socket on the motherboard.
3. Align the notch of the IPMI card with the socket key in the slot.
4. Insert at 30 degrees into the socket until it is fully seated in the connector.
5. Push down on the IPMI card and secure it with one (1) screw.







## Installing M.2 SATA Storage (Optional)

NCA-6040 supports one M.2 slot for additional SATA storage expansion. Please follow the steps for installation

1. Power off the system and open the chassis cover.
2. Locate the M.2 slot on the motherboard.



3. Align the notches of the M.2 storage module with the socket key in the pin slot.
4. Insert the module at 30 degrees into the socket until it is fully seated.





5. Push down on the module and secure it with a screw




## Installing M.2 SSD Storage (Optional)

NCA-6040 supports two M.2 slot for additional NVMe storage expansion. Please follow the steps for installation.

1. Power off the system and open the chassis cover.
2. Unscrew the seven (7) screws of the fan hood/shroud and PCIe bracket cover on the rear panel. Lift up the fan hood/shroud and PCIe slot bracket cover. Locate the two M.2 slots on the motherboard.




3. Align the notch of the M.2 storage module with the socket key in the pin slot.





4. Insert the M.2 storage module at 30 degrees into the socket until it is fully seated.



5. Push down on the module and secure with a screw.




6. Repeat steps if installing a second storage module.

## Installing DPU Expansion Card (Optional)


NCA-6040 supports one PCIe x8 FH/FL slot for DPU card expansion. The DPU card requires a rather complex installation process; therefore, the assembly must be handled with care. Please read through the instructions in this section to make sure you have acquired the necessary knowledge and comply with the requirements.

1. The DPU Expansion Kit will include:


- ▶ 1x DPU Module
- ▶ 1x Riser Card
- ▶ 2x Swappable Fans
- ▶ Screw packet




2. Power off the system and open the chassis cover.
3. Unscrew the seven (7) screws of the fan hood/shroud and PCIe bracket cover, on the rear panel. Lift up the fan hood/shroud and PCIe slot bracket cover.




4. Pick up the PCIe bracket, and the Riser card. Place the Riser card on the side of the bracket and secure with four (4) screws.




5. Next, we install the fans to the PCIe bracket. Secure the fan with four (4) screws each.



6. Then, connect the fan power cables to the Riser Card.




7. Pick up the PCIe bracket, unscrew the four (4) screws on the side to remove the side metal partition. And unscrew the three (3) screws to remove the metal holder.




8. Align the DPU module to the PCIe socket. Slide the DPU module into the PCIe socket until it is completely seated.

Make sure the side bar slides in properly (as pictured below).








9. Place the metal holder on the side of the DPU module, and secure with the original three (3) screws. Then place the metal partition back in place and secure with the original four (4) screws.



10. Align the socket key of the Riser Card to the socket key on the motherboard. Gently insert until it is firmly seated. Then, secure the PCIe bracket with the original three (3) screws.




11. Lastly, insert the DPU power cable to the DPU module. The fan hood/shroud can also be secured back on the motherboard.



## Installing the Disk Drive(s)

NCA-6040 is built with two 3.5" or 2.5" HDD/SSD slot drive bay. Please follow the steps for installation.


1. Power off the system. Locate the 3.5" disk bay on the front panel.



2. To remove the tray, push down on the tab for the tab lever to slide open, and then hold the tab lever to pull out the tray.



3. Slide one 3.5"/2.5" HDD/SSD into the tray, and secure with two (2) screws on each side. Make sure the disk SATA contacts are facing outwards.



4. Place the mounted disk tray back into position in the system. Gently push the tray until it is firmly seated and press the tab lever until it clicks into place.




## Installing the NIC Modules

NCA-6040 comes with 8 NIC Ethernet module slots for network bandwidth expansion. Please follow the steps for installation.


1. On the front panel, select a NIC Module slot.



2. Rotate clockwise and loosen the two lock-screws to remove the door.



3. Insert a NIC module.



4. Once the module is firmly seated, rotate counter-clockwise and tighten the two lock-screws.





## Replacing the Cooling Fans

Cooling fans may wear down eventually. Please refer to the steps below for replacing cooling fans. When using a new cooling fan, simply reverse the steps to install the fan back onto the enclosure and the system.

1. Locate the cooling fans at the rear panel.



2. Using a screwdriver, loosen the two (2) lock-screws of the fan you would like to replace.



3. Hold onto the two lock-screws and pull it out.



4. Insert a new fan. Push the fan unit in until it clicks into place and secure with the two (2) lock-screws.


## Replacing the Power Supply Units

Power supply units may wear down eventually. The NCA-6040 series is compatible with 1300W PSU. Ensure to use power supply units that align with this capacity.

1. On the rear panel, locate the power supply units and disconnect the power cords.



2. Press and hold the handle to pull out the power supply unit.



3. Insert a new power supply unit. Push the unit in until it clicks into place.





## Mounting the System

The system offers the option to be rack-mounted using the separately sold Slide Rail Kit and Short Mounting Ear brackets. The sliding rack-mount rails facilitate easy access to the system and ensure it is securely anchored in the rack. Please proceed with the following steps for installation.



The Slide Rail Kit can secure the system while providing sufficient weight support for the device.

1. Check the package contents of the Slide Rail Kit. The kit shall include the following items:

- ▶ #1 pack of 12pcs M4x4 screws
- ▶ #2 pack of 2pcs M4x4 screws
- ▶ 2x Slide Rails



#1 Screw Pack




#2 Screw Pack



Slide Rails


The rail consists of the following parts:




### **Assembling the Ear Brackets**

1. Check the package contents. The supplied mounting kit shall include the items below:

- ▶ 2x Standard Ear Brackets
- ▶ 1x pack of screws




2. Install the ear brackets on both sides of the system using the provided screws, two (2) screws on each side.




### **Attaching the Rail Brackets**

1. Unpack a slide rail and slide the **inner channel** all the way to the end.
2. Remove the **rail bracket** from the **inner channel** by pushing the Release Tab on the **rail bracket** outwards while sliding it out. Stretch the **rail bracket** to the fullest.
3. Attach six (6) screws on each side of the system.



4. Align the **rail bracket** keyholes to the six (6) screws on the side of the system. Then slide and lock the bracket in place.




5. Last step, screw in the one (1) screw (from #2 Screw Pack) on each side to secure the rail bracket to the system.




### **Installing the Slide Rails**

Next, you shall install the slide rail assemblies onto the rack.

1. This slide-rails does NOT require screw-fixing. Simply aim at three (3) available screw holes on the rack front and snap the rail (outer channel) front into the rack post, as shown in the image below. You should hear a "click" sound once it is firmly attached.




2. For the rear rack installation, slide the rail (outer channel) to aim and engage the bolts on the rail's rear end with the two (2) available holes on the post, and the rail assembly will click into place.




### Installing the System into the Rack


1. Stretch both of the **inner channel** out to their fullest extent. You will hear a click sound when they are fully stretched and locked.



2. Hold the system with its front facing you, lift the chassis and gently engage the **rail brackets** with the **inner channel**, as shown in the image below, and then push the system into the cabinet.



3. When pushing in the system, please also push and hold the Rail Lock tab on both brackets.





4. The system has completed installation in the rack.



### **Removing the System from the Rack**

1. To remove the system from the rack, gently pull it outwards towards you, while pushing the Release Tab on both sides of the **rail brackets**.



## CHAPTER 4: REMOTE SERVER MANAGEMENT (SKU A/SKU B)

### BMC Overview

This document specifies the BMC firmware features. The BMC firmware implements IPMI 2.0 based on ASPEED service processor. It performs all the BMC management tasks defined by IPMI 2.0.

In addition, BMC firmware runs an embedded web-server for full configuration using Web UI, which has a low learning curve.

### BMC Main Features

Feature		Description
<b>IPMI 2.0 Standard Features</b>	System Interface support	<ul style="list-style-type: none"> <li>• KCS (System Interface Support)</li> <li>• LAN (RMCP+)</li> </ul>
	IPMI 2.0 based Management	<ul style="list-style-type: none"> <li>• BMC stack with an IPMI 2.0 implementation</li> <li>• Sensor monitoring</li> <li>• System power management</li> </ul>
	System Management	<ul style="list-style-type: none"> <li>• Watchdog timer</li> <li>• Fan speed monitor</li> <li>• FRU information</li> </ul>
	Event Log	<ul style="list-style-type: none"> <li>• System Event Log (SEL)</li> </ul>
	Text Console Redirection: SOL	<ul style="list-style-type: none"> <li>• Support in IPMI stack for SOL to remotely access BIOS and text console before OS booting</li> </ul>
	User Management	<ul style="list-style-type: none"> <li>• IPMI based user management</li> <li>• Multiple user permission level</li> </ul>
<b>Non-IPMI functions</b>	Web User Interfaces	<ul style="list-style-type: none"> <li>• BMC management via web user interface</li> <li>• Integrated KVM and Virtual Media</li> </ul>
	User authorization	<ul style="list-style-type: none"> <li>• RADIUS support</li> <li>• LDAP support</li> </ul>
	Security	<ul style="list-style-type: none"> <li>• SSL and HTTPS support</li> </ul>
	Maintenance	<ul style="list-style-type: none"> <li>• Auto-sync time with NTP server</li> <li>• Remote firmware update by Web UI or Linux tool</li> </ul>

## Firmware Functional Description

### System health monitoring

The BMC implements system sensor monitoring feature. It could monitor voltage, temperature and current of critical components.

### System Power Management

The BMC implements chassis power and reset functions for system administrators to control and manage the system power behavior. These functions can be activated by sending the IPMI 2.0 compatible chassis commands to the BMC over messaging interfaces. The following list summaries the supported functions.

- Chassis power on
- Chassis power off
- Chassis power cycle
- Chassis power reset
- Chassis power soft
- Server's power status report

### Watchdog Timer

The BMC provides an IPMI 2.0 compatible watchdog timer which can prevent the system from system hanging.

### Field Replaceable Unit (FRU)

The BMC implements an interface for logical FRU inventory devices as specified in IPMI 2.0 specification. This functionality provides commands for system administrators to access and management the FRU inventory information.

### System Event Log (SEL)

A non-volatile storage space is allocated to store system events for system status tracking.

### Serial over LAN (SOL)

IPMI 2.0 SOL is implemented to redirect the system serial controller traffic over an IPMI session. System administrators can establish a SOL connection with a standard IPMI client, like IPMITOOL, to remotely interact with serial text-based interfaces such as OS command-line and serial redirected BIOS interfaces.



## User Management

The BMC supports 9 IDs for IPMI user accounts. The maximum length of the username and password are 16 and 20 respectively, and the possible privilege levels are Callback, User, Operator, and Administrator. Moreover, the account creator can enable/disable the user account at any time. If not specified, the default user accounts are listed follows:

User Name	Password	User Access	Characteristics
admin	admin	Enabled	Password can be changed

## Keyboard, Video, Mouse (KVM) Redirection

- The BMC provides keyboard, video, and mouse (KVM) redirection over LAN. This application is available remotely from the embedded web server.
- Support video recording, recorded videos to be downloaded & playable.

## Virtual Media Redirection

- The BMC provides remote virtual CD, HD and FD redirection. CD image could be mounted directly in KVM window. HD, FD could be mounted by NFS and SAMBA.
- Efficient USB 2.0 based CD/DVD redirection with a typical speed of 20XCD.
- Completely secured transmission.


## IPMI Commands Support List

COMMANDS	NETFN	CMD
<b>IPM Device “Global” Commands</b>		
Get Device ID	APP (06h)	00h
Cold Reset	APP (06h)	02h
Warm Reset	APP (06h)	03h
Get Device GUID	APP (06h)	08h
<b>BMC Watchdog Timer Commands</b>		
Reset Watchdog Timer	APP (06h)	22h
Set Watchdog Timer	APP (06h)	24h
Get Watchdog Timer	APP (06h)	25h
<b>BMC Device and Messaging Commands</b>		
Get System GUID	APP (06h)	37h
Get Channel Info	APP (06h)	42h
Set User Access	APP (06h)	43h
Get User Access	APP (06h)	44h
Set User Name	APP (06h)	45h
Get User Name	APP (06h)	46h
Set User Password	APP (06h)	47h
<b>Chassis Device Commands</b>		
Get Chassis Capabilities	Chassis (00h)	00h
Get Chassis Status	Chassis (00h)	01h
Chassis Control	Chassis (00h)	02h
Chassis Reset	Chassis (00h)	03h
<b>Sensor Device Commands</b>		
Get Sensor Reading Factors	S/E (04h)	23h
Get Sensor Hysteresis	S/E (04h)	25h
Get Sensor Threshold	S/E (04h)	27h
Get Sensor Event Enable	S/E (04h)	29h
Get Sensor Event Status	S/E (04h)	2Bh
Get Sensor Reading	S/E (04h)	2Dh
Get Sensor Type	S/E (04h)	2Fh
<b>FRU Device Commands</b>		
Get FRU Inventory Area Info	Storage (0Ah)	10h
Read FRU Data	Storage (0Ah)	11h
Write FRU Data	Storage (0Ah)	12h
<b>SDR Device Commands</b>		
Get SDR Repository Info	Storage (0Ah)	20h
Get SDR Repository Allocation Info	Storage (0Ah)	21h
Get SDR	Storage (0Ah)	23h
Get SDR Repository Time	Storage (0Ah)	28h
<b>SEL Device Commands</b>		
Get SEL Info	Storage (0Ah)	40h
Get SEL Allocation Info	Storage (0Ah)	41h
Get SEL Entry	Storage (0Ah)	43h

Delete SEL Entry	Storage (0Ah)	46h
Clear SEL	Storage (0Ah)	47h
Get SEL Time	Storage (0Ah)	48h
Set SEL Time	Storage (0Ah)	49h
Get SEL Time UTC Offset	Storage (0Ah)	5Ch
Set SEL Time UTC Offset	Storage (0Ah)	5Dh
<b>LAN Device Commands</b>		
Set LAN Configuration Parameters	Transport (0Ch)	01h
Get LAN Configuration Parameters	Transport (0Ch)	02h
<b>Serial/Modem Device Commands</b>		
Set User Callback Options	Transport (0Ch)	1Ah
Get User Callback Options	Transport (0Ch)	1Bh
SOL Activating	Transport (0Ch)	20h
Set SOL Configuration Parameters	Transport (0Ch)	21h
Get SOL Configuration Parameters	Transport (0Ch)	22h

## Using BMC Web UI

In the address bar of your Internet browser, input the IP address of the remote server to access the BMC interface of that server.



Initial access of BMC prompts you to enter the User Name and Password. A screenshot of the login screen is given below:

A screenshot of the BMC Management login page. The page has a dark grey header on the left with the text "BMC Management" in white. The main area is light grey and contains two input fields: "Username" with a user icon and "Password" with a lock icon. A green "Login" button is located at the bottom right.

*Login Page*

- ▶ **Username:** Enter your username in this field.
- ▶ **Password:** Enter your password in this field.
- ▶ **Sign me in:** After entering the required credentials, click the **Sign me in** to log in to Web UI.




**Note:** (1) If not specified, the default IP to access BMC is <https://192.168.0.100>.  
(2) Please use **https** to access Web UI.

## Default User Name and Password

- ▶ **Username:** admin
- ▶ **Password:** admin

The default username and password are in lower-case characters. When you log in using the default username and password, you will get full administrative rights, and it will ask you to change the default password once you log in. The dialog is shown below:



Change the password for the default user. The password must contain 8 to 16 characters.


Password must follow these rules:

1. Cannot contain all of the user's account name.
2. Includes three of the following four categories:
  - a. English uppercase characters.
  - b. English lowercase characters.
  - c. Numbers 0 to 9.
  - d. Non-alphanumeric characters (~!@#\$%^&\*).

OK

*Change the default password - Dialog*

Clicking **OK** will take you to set a password.



**BMC Management**

New password

Confirm password

Submit

*Change the default password – Set password*



**Note:** Duplicate usernames shouldn't exist across various authentication methods like LDAP, RADIUS or IPMI since the privilege of one Authentication method is overwritten by another authentication method during logging in, and hence the correct privilege cannot be returned properly.


## First Time Wizard

After the first-time login, you will see first time wizard welcome page as the following picture. Please press the "Next" button and configure your BMC step by step.

On the "IPv4", "IPv6" and "DNS" pages, you could specify the hostname and network settings of BMC.

On the "Remote Control" page, you could specify allowed IP region which could access KVM and Remote media web pages.

On the "Date and Time" page, you could specify the NTP and time settings.



In the final page, please press "Finish" button to complete the first-time wizard. BMC will be rebooted and apply new settings. You could reconnect to the Web UI after a few minutes.

## Web UI Layout

The BMC Web UI consists of various menu items:


### Menu Bar

The menu bar displays the following:

- ▶ Dashboard
- ▶ Appliance – FRU Information
- ▶ Appliance – Sensor Reading
- ▶ Appliance – Event Log
- ▶ Appliance – Remote Media Settings
- ▶ Appliance – KVM RMedia Settings
- ▶ Appliance – Image Redirection
- ▶ BMC Config – Date and Time
- ▶ BMC Config – User Configuration – User List
- ▶ BMC Config – User Configuration – RADIUS Setup
- ▶ BMC Config – User Configuration – LDAP Setup
- ▶ BMC Config – User Configuration – LDAP Groups
- ▶ BMC Config – User Configuration – Login Block Settings
- ▶ BMC Config – Network Configuration – IP Settings
- ▶ BMC Config – Network Configuration – DNS Settings
- ▶ BMC Config – Network Configuration – Link Settings
- ▶ BMC Config – Network Configuration – SSL Certificate
- ▶ BMC Config – Network Configuration – Services
- ▶ BMC Config – Network Configuration – Remote Syslog
- ▶ BMC Config – Audit Log
- ▶ BMC Config – Maintenance – Firmware Update
- ▶ BMC Config – Maintenance – Restore Factory Defaults
- ▶ BMC Config – Maintenance – Preserve Configuration




A screenshot of the menu bar is shown below:




Menu Bar

### Quick Button and Logged-in User


The user information and quick buttons are located at the top right of the Web UI.



User Information



**Logged-in user information:** Click the icon  **admin** ▼ to view the logged-in user information.

A screenshot of the logged-in user information is shown below:



Logged-in User Information

The logged-in user information shows the logged-in user's username, privilege, with the quick buttons allowing you to perform the following functions:


- ▶ **Refresh:** Click the icon  to reload the current page.
- ▶ **Sign out:** Click the icon  to log out of the Web UI.

## Logged-in user and its privilege level

This option shows the logged-in username and privilege. There are four kinds of privileges:

- ▶ **User:** Only valid commands are allowed.
- ▶ **Operator:** All BMC commands are allowed except for the configuration commands that can change the behavior of the out-of-hand interfaces.
- ▶ **Administrator:** All BMC commands are allowed.
- ▶ **No Access:** Login access denied.

## Help

**Help:** The **Help** icon  is located at the top right of each page in Web UI. Click this help icon to view more detailed field descriptions.

## CHAPTER 5: BIOS SETUP

The system has AMI BIOS built-in, with a SETUP utility that allows users to configure required settings or to activate certain system features. Pressing the <Tab> or <DEL> key immediately allows you to enter the Setup Utility.

### Enter BIOS Setup

To enter the BIOS setup utility, simply follow the steps below:


1. Boot up the system.
2. Pressing the <Tab> or <Del> key immediately allows you to enter the Setup utility, then you will be directed to the BIOS main screen. The instructions for BIOS navigations are as below:

Control Keys	Description
→←	select a setup screen
↑↓	select an item/option on a setup screen
<Enter>	select an item/option or enter a sub-menu
+/-	adjust values for the selected setup item/option
F1	display General Help screen
F2	retrieve previous values, such as the last configured parameters during the last time you entered BIOS
F3	load optimized default values
F4	save configurations and exit BIOS
<Esc>	exit the current screen

## Main Page

Setup Main Page contains BIOS information and project version information.


(The screenshots presented in this section are for reference only)



Item	Description
BIOS Information	BIOS Vendor: American Megatrends Core Version: AMI Kernel version, CRB code base, X64 Compliance : UEFI version, PI version Project Version: BIOS release version Build Date and Time: MM/DD/YYYY CPLD Project Version: CPLD release version Access Level: Administrator / User
Memory Information	Total Memory: by case
System Date	To set the Date, use <Tab> to switch between Date elements. Default Range of Year: 2005-2099 Default Range of Month: 1-12 Days: dependent on Month.
System Time	To set the Date, use <Tab> to switch between Date elements.


## Advanced Setup

Select the **Advanced** menu item from the BIOS setup screen to enter the “Advanced” setup screen. Users can select any of the items in the left frame of the screen.







Trusted Computing



Feature	Option	Description
Security Device Support	<div>Enabled</div> <div>Disabled</div>	Enables or disables BIOS support for security device. By disabling this function, OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

**Trusted Computing (TPM2.0)**

Feature	Options	Description
Security Device Support	Enabled Disabled	Enables or disables BIOS support for security device. By disabling this function, OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
SHA256 PCR Bank	Enabled Disabled	Enables or disables SHA256 PCR Bank.
Pending Operation	None TPM Clear	Schedules an Operation for the Security Device. <b>NOTE:</b> Your computer will reboot during restart in order to change State of Security Device.


Platform Hierarchy	Enabled Disabled	Enables or disables Platform Hierarchy.
Storage Hierarchy	Enabled Disabled	Enables or disables Storage Hierarchy.
Endorsement Hierarchy	Enabled Disabled	Enables or disables Endorsement Hierarchy.
Physical Presence Spec Version	1.2 1.3	Select to tell OS to support PPI Spec Version 1.2 or 1.3. <b>NOTE:</b> Some HCK tests might not support 1.3.
TPM 20 Interface Type	TIS	Select <b>TPM 20 Device</b> for the Communication Interface.



FAN4A Speed	This value reports the Fan4A speed
FAN4B Speed	This value reports the Fan4B speed
1V5V	This value reports the 1.05V Input voltage
VDIMM	This value reports the Memory Input voltage
CPU VCORE	This value reports the CPU VCORE Input voltage
VSBS5V	This value reports the Standby 5V Input voltage
5V	This value reports the 5V Input voltage
12V	This value reports the 12V Input voltage
P3V3	This value reports the 3.3V Input voltage
VBA	This value reports the VBAT Input voltage
VSBS3.3V	This value reports the Standby 3.3V Input voltage




Smart Fan Mode Configuration




Feature	Option	Description
Fan Out Mode	Full Speed Mode	Fan Mode Select
	Smart Fan Mode	

## F81804 Super IO Configuration




Serial Port 1 Configuration




Feature	Option	Description
Serial Port	Disabled	Enable or Disable Serial Port (COM)
	Enabled	
Device Settings	N/A	IO=3F8h; IRQ=4;

Serial Port 2 Configuration



Feature	Option	Description
Serial Port	Disabled	Enable or Disable Serial Port (COM)
	Enabled	
Device Settings	N/A	IO=2F8h; IRQ=3;

## Console Redirection Settings




Feature	Option	Description
Terminal Type	VT100 VT100+ VT-UTF8 ANSI	VT100: ASCII char set VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes ANSI: Extended ASCII char set
Bits per second	9600 19200 38400 57600 115200	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Data Bits	7 8	Data Bits
Parity	None Even Odd Mark Space	A parity bit can be sent with the data bits to detect some transmission errors.
Stop Bits	1 2	Indicates the end of a serial data packet.
Flow Control	None Hardware RTS/CTS	Flow Control can prevent data loss from buffer overflow.
VT-UTF8 Combo Key Support	Disabled Enabled	Enables VT-UTF8 Combination Key Support for ANSI/VT100 terminals

Recorder Mode	Disabled Enabled	With this mode enabled, only text will be sent. This is to capture Terminal data.
Resolution 100x31	Disabled Enabled	Enables or disables extended terminal resolution
Putty Keypad	VT100 LINUX XTERM86 SCO ESCN VT400	Selects Function Key and Keypad on Putty.




## PCI Subsystem Settings




Feature	Option	Description
Above 4G Decoding	Enabled Disabled	Enables or disables 64bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64 bit PCI Decoding)
SR-IOV Support	Disabled Enabled	If the system has SR-IOV capable PCIe Devices, this option enables or disables Single Root IO Virtualization Support.

## USB Configuration




Feature	Option	Description
Legacy USB Support	Enabled Disabled Auto	Enables Legacy USB support. <b>Auto</b> option disables legacy support if no USB devices are connected; <b>Disabled</b> option will keep USB devices available only for EFI applications.
XHCI Hand-off	Enabled Disabled	This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enabled Disabled	Enables or disables USB Mass Storage Driver Support.
USB transfer time-out	1 sec 5 sec 10 sec 20 sec	The time-out value for Control, Bulk, and Interrupt transfers
Device reset time-out	1 sec 5 sec 10 sec 20 sec	USB mass storage device Start Unit command time-out
Device power-up delay	Auto Manual	Maximum time the device will take before it properly reports itself to the Host Controller. <b>Auto</b> uses default value: for a Root port, it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

## Network Stack Redirection




Feature	Option	Description
Network Stack	Disabled Enabled	Enables or disables UEFI Network Stack
Ipv4 PXE Support	Disabled Enabled	Enables Ipv4 PXE Boot Support. If IPV4 is disabled, PXE boot option will not be created.
Ipv4 HTTP Support	Disabled Enabled	Enables Ipv4 HTTP Boot Support. If IPV4 is disabled, HTTP boot option will not be created.
Ipv6 PXE Support	Disabled Enabled	Enables Ipv6 PXE Boot Support. If IPV6 is disabled, PXE boot option will not be created.
Ipv6 HTTP Support	Disabled Enabled	Enables Ipv6 HTTP Boot Support. If IPV6 is disabled, HTTP boot option will not be created.
PXE boot wait time	0	Wait time to press <ESC> key to abort the PXE boot
Media detect count	1	Number of times the presence of media will be checked

NVMe Configuration




Control PXE Boot



Feature	Option	Description
Control PXE Boot	Disabled	
	Lan1	Control PXE Boot from which Lan
	Lan2	

## Platform Setup


Select the Platform menu item from the BIOS setup screen to enter the Platform Setup screen. Users can select any of the items in the left frame of the screen.



Feature	Option	Description
PCH Configuration	None	Displays and provides option to change the PCH Settings
Server ME Configuration	None	Configure Server ME Technology Parameters
Restore AC Power Loss	Power On Power Off Last State	Select S0/S5 for ACPI state after a G3




## PCH-IO Configuration






Item	Option	Description
SATA and RST Configuration	None	Device options settings

Controller 1 SATA and RST Configuration



Feature	Option	Description
Controller 1 SATA and RST Configuration	None	SATA Controller 1 Device Options Settings

**PCH SATA and RST Configuration**




Feature	Option	Description
SATA Configuration	Disabled <b>Enabled</b>	Enables or disables SATA Controller
SATA Mode Selection	<b>AHCI</b> RAID	This will configure SATA as <b>RAID</b> or <b>AHCI</b> .
SATA Port 0/2/3/4/5	Disabled <b>Enabled</b>	Enable or Disable SATA Port
Hot Plug 0/2/3/4/5	<b>Disabled</b> Enabled	Designates this port as Hot Pluggable.
Spin Up Device	<b>Disabled</b> Enabled	If enabled for any of ports Staggered Spin Up will be performed and only the drives switch has this option enabled will spin up at boot. Otherwise all drives spin up at boot.
SATA Device Type	<b>Hard Disk Drive</b> Solid State Drive	Identify the SATA port is connected to Solid State Drive or Hard Disk Drive

Server ME Configuration



# Socket Configuration


Select the Socket menu item from the BIOS setup screen to enter the Socket Setup screen. Users can select any of the items in the left frame of the screen.



Feature	Option	Description
Processor Configuration	None	Displays and provides option to change the Processor Settings
Memory Configuration	None	Displays and provides option to change the Memory Settings
IIO Configuration	None	Displays and provides option to change the IIO Settings
Advanced Power Management Configuration	None	Displays and provides option to change the Power Management Settings




## Processor Configuration




Feature	Option	Description
Enable LP(Global)	<b>ALL LPs</b> Single LP	Enables Logical processor (Software Method to Enable/Disable Logical Processor threads).
Machine Check	<b>Disabled</b> <b>Enabled</b>	Enable or Disable the Machine Check
Hardware Prefetcher	<b>Disabled</b> <b>Enabled</b>	= MLC Streamer Prefetcher (MSR 1A4h Bit [0])
Adjacent Cache Prefetcher	<b>Disabled</b> <b>Enabled</b>	= MLC Spatial Prefetcher (MSR 1A4h Bit [1])
Extended APIC	<b>Disabled</b> Enabled	Enables or disables extended APIC support
Enable Intel® TXT	<b>Disabled</b> Enabled	Enables Intel(R) TXT
VMX	<b>Disabled</b> <b>Enabled</b>	Enables the Vanderpool Technology, which takes effect after reboot.
Enable SMX	<b>Disabled</b> Enabled	Enables Safer Mode Extensions

CPU Socket0 Configuration




Feature	Option	Description
Disable Bitmap (Hex)	0	0: Enable all cores. FFFFFFFF: Disable all cores least one core per CPU must be enabled. Disabling all cores is an invalid configuration.

Memory Configuration




Feature	Option	Description
Memory Frequency	Auto	Maximum Memory Frequency Selections in Mhz. Do not select Reserved
	3200	
	3600	
	4000	
	4400	
	4800	
	5200	
	5600	
Memory Topology	None	Displays memory topology with DIMM population information

## I/O Configuration




Feature	Option	Description
Socket0 Configuration	None	None
Intel® VT for Directed I/O (VT-d)	None	Press <b>&lt;Enter&gt;</b> to bring up the Intel® VT for Directed I/O (VT-d) Configuration menu.
PCI-E ASPM Support (Global)	Disable Per-Port	This option Disable/ Per-Port the ASPM support for all downstream devices.
PCIe Extended Tag Enable	Disable Auto	Auto/Disable - BIOS sets 8-bit Tag Field for PCIe Root Port/End Point. Disable - BIOS sets 5-bit Tag Field for PCIe Root Port/End Point
PCIe Max Read Request Size	Auto 128B 256B 512B 1024B 2048B 4096B	Set Max Read Request Size in End Points

## Socket0 Configuration




Feature	Option	Description
Port DMI	None	Settings related to PCI Express Port DMI
Port 1A	None	Settings related to PCI Express Port 1A
Port 1E	None	Settings related to PCI Express Port 1E
Port 2A	None	Settings related to PCI Express Port 2A
Port 2E	None	Settings related to PCI Express Port 2E
Port 3A	None	Settings related to PCI Express Port 3A
Port 3E	None	Settings related to PCI Express Port 3E
Port 4A	None	Settings related to PCI Express Port 4A
Port 4E	None	Settings related to PCI Express Port 4E
Port 5A	None	Settings related to PCI Express Port 5A
Port 5C	None	Settings related to PCI Express Port 5C
Port 5E	None	Settings related to PCI Express Port 5E

Advanced Power Management Configuration




Feature	Option	Description
CPU P State Control	None	P State Control Configuration Sub menu, include Turbo, XE, etc.
CPU C State Control	None	CPU C State Settings



**CPU P State Control**

Feature	Option	Description
SpeedStep (Pstates)	Disabled Enabled	Enables or disables EIST (P-States)
Boot Performance Mode	Max Performance Max Efficient Set by Intel Node Manager	Select the performance state that the BIOS will set before OS hand off.
CPU Flex Ratio Override	Disabled Enabled	Enable/Disable CPU Flex Ratio Programming
CPU Core Flex Ratio	23	Non-Turbo Mode Processor Core Ratio Multiplier


CPU C State Control



Feature	Option	Description
CPU C1 auto demotion	Disabled Enabled	Autonomous Core C-State Control
Enhanced Halt State (C1E)	Disabled Enabled	Core C1E auto promotion Control. Takes effect after reboot.

## Server Mgmt (SKU A / SKU B)

Use [→] or [←] to select [Server Mgmt] setup screen. Under this screen, you may use [↑][↓] to select an item you want to configure.




Feature	Option	Description
BMC Support	<b>Enabled</b> Disabled	Enable or disables interfaces to communicate with BMC.
Wait For BMC	Enabled <b>Disabled</b>	Wait For BMC response for specified time out. In PILOTII, BMC starts at the same time when BIOS starts during AC power ON. It takes around 30 seconds to initialize Host to BMC interfaces.
FRB-2 Timer	<b>Enabled</b> Disabled	Enables or disables FRB-2 timer (POST timer).
FRB-2 Timer timeout	3 minutes 4 minutes 5 minutes <b>6 minutes</b>	Enter value Between 3 to 6 min for FRB-2 Timer Expiration value.
FRB-2 Timer Policy	<b>Do Nothing</b> Reset Power Down Power Cycle	Configure how the system should respond if the FRB-2 Timer expires. Not available if FRB-2 Timer is disabled.
OS Watchdog Timer	Enabled <b>Disabled</b>	If enabled, it starts a BIOS timer which can only be shut off by Management Software after the OS loads. It also helps verify that the OS is successfully loaded or follows the OS Boot Watchdog Timer policy.

OS Wtd Timer Timeout	10 minute	Configure the length of the OS Boot Watchdog Timer. Not available if OS Boot Watchdog Timer is disabled.
OS Wtd Timer Policy	Reset	Configure how the system should respond if the OS Boot Watchdog Timer expires. Not available if OS Boot Watchdog Timer is disabled.
System Event Log	NA	Press <Enter> to change the SEL event log configuration.
BMC network configuration	NA	Configure BMC network parameters.
View System Event Log	NA	Press <Enter> to view the System Event Log Records.
BMC Warm Reset	NA	Press <Enter> to do Warm Reset BMC.

## Server Mgmt (SKU C)


Use [→] or [←] to select [Server Mgmt] setup screen. Under this screen, you may use [↑][↓] to select an item you want to configure.



Feature	Option	Description
BMC Support	Disabled	This platform (SKU) doesn't support BMC.

## System Event Log (SKU A/SKU B)

Use this option to change the SEL event log configuration.



Feature	Option	Description
SEL Components	Disabled <b>Enabled</b>	Enables or disables all features of System Event Logging during boot.
Erase SEL	<b>NO</b> Yes, On next reset Yes, On every reset	Choose options for erasing SEL.
When SEL is Full	<b>Do Nothing</b> Erase Immediately Delete Oldest Record	Choose options for reactions to a full SEL.




## BMC Network Configuration (SKU A/SKU B)

This option allows you to configure BMC network parameters.

Aptio Setup - AMI		Server Mgmt
--BMC network configuration-- *****		^ Select to configure LAN ^
Configure IPv4 support *****		* channel parameters *
		* statically or *
		* dynamically (by BIOS or *
		* BMC). Unspecified *
		* option will not modify *
		* any BMC network +
		+ parameters during BIOS v
		+ -----
		+ ><: Select Screen
		+ ^v: Select Item
		+ Enter: Select
		+ +/-: Change Opt.
		+ F1: General Help
		+ F2: Previous Values
		+ F3: Optimized Defaults
		v F4: Save & Exit
		ESC: Exit
Lan channel 1		
Configuration Address	[Unspecified]	
source		
Current Configuration	StaticAddress	
Address source		
Station IP address	192.168.0.100	
Subnet mask	255.255.255.0	
Station MAC address	3A-0F-60-45-74-A7	
Router IP address	0.0.0.0	
Router MAC address	00-00-00-00-00-00	
Lan channel 2		
Version 2.22.1285 Copyright (C) 2022 AMI		AB


Aptio Setup - AMI		Server Mgmt
Current Configuration Unspecified		^ Enable VLAN Support to
Address source		+ specify the 802.1q VLAN
Station IP address 0.0.0.0		+ ID
Subnet mask 0.0.0.0		+
Station MAC address 00-00-00-00-00-00		+
Router IP address 0.0.0.0		+
Router MAC address 00-00-00-00-00-00		+
*****		*
Configure VLAN support *****		* -----
		* ><: Select Screen
		* ^v: Select Item
		* Enter: Select
		* +/-: Change Opt.
		+ F1: General Help
		+ F2: Previous Values
		+ F3: Optimized Defaults
		v F4: Save & Exit
		ESC: Exit
Lan channel 1		
VLAN Support	[Unspecified]	
Current Configuration	Disabled	
Address source		
VLAN ID	0	
Version 2.22.1285 Copyright (C) 2022 AMI		AB



Feature	Option	Description
Configuration	<b>Unspecified</b>	Select to configure LAN channel parameters statically or dynamically (by BIOS or BMC). The <b>unspecified</b> option will not modify any BMC network parameters during BIOS phase.
Address source	Static	
	DynamicBmcDhcp	
	DynamicBmcNonDhcp	


## View System Event Log (SKU A/SKU B)

This option allows you to view the System Event Log Records.



## Security Setup

Select the Security menu item from the BIOS setup screen to enter the Security Setup screen. Users can select any of the items in the left frame of the screen.




Feature	Description
Administrator Password	If ONLY the Administrator's password is set, it only limits access to Setup and is only asked for when entering Setup.
User Password	If ONLY the User's password is set, it serves as a power-on password and must be entered to boot or enter Setup. In Setup, the User will have Administrator rights.




## Secure Boot

This option allows you to customize Secure Boot settings.



Feature	Option	Description
Secure Boot	Disabled Enabled	Secure Boot is activated when Platform Key (PK) is enrolled, System mode is User/Deployed, and CSM function is disabled.
Secure Boot Mode	Standard Custom	Secure Boot mode selector: In <b>Custom</b> mode, Secure Boot Variables can be configured without authentication

## Key Management




Feature	Option	Description
Factory Key Provision	Disabled	Provision factory default keys on next re-boot only when System in Setup Mode.
Restore Factory keys	None	Force System to User Mode. Configure NVRAM to contain OEM-defined factory default Secure Boot keys.
Enroll Efi Image	None	Allows the image to run in Secure Boot mode. Enroll SHA256 hash of the binary into Authorized Signature Database (db)



## Boot Setup

Select the Boot menu item from the BIOS setup screen to enter the Boot Setup screen. Users can select any of the items in the left frame of the screen.




Item	Option	Description
Setup Prompt Timeout	5	The Number of seconds to wait for setup activation key. 65535 means indefinite waiting.
BootupNumLock State	On Off	Select the keyboard NumLock state.
Quiet Boot	Disabled Enabled	Enables or disables Quiet Boot option.

- Choose boot priority from boot option group.
- Choose specific boot device priority sequence from available Group device.


## Save and Exit Setup

Select the Save and Exit menu item from the BIOS setup screen to enter the Save and Exit Setup screen. Users can select any of the items in the left frame of the screen.



### ■ Discard Changes and Exit

Select this option to quit Setup without saving any modifications to the system configuration. The following window will appear after the "Discard Changes and Exit" option is selected. Select "Yes" to discard changes and Exit Setup.




### ■ Save Changes and Reset

When Users have completed the system configuration changes, select this option to save the changes and reset from BIOS Setup in order for the new system configuration parameters to take effect. The following window will appear after selecting the "Save Changes and Reset" option is selected. Select "Yes" to Save Changes and reset.



### ■ Restore Defaults


Restore default values for all setup options. Select “**Yes**” to load Optimized defaults.



Note: The items under Boot Override may not be the same images as above, as it would depend on the actual devices connected to the system.

# APPENDIX A: LED INDICATOR EXPLANATIONS

The status explanations of LED indicators on Front Panel are as follows:



## ► System Power

<i>Solid Green</i>	<i>The system is powered on</i>
<i>Off</i>	<i>The system is powered off</i>

## ► System Status


This LED indicator is programmable. You could program it to display the operating status of the behaviors described below:

<i>Solid Green</i>	<i>Defined by GPIO</i>
<i>Solid Red</i>	<i>Defined by GPIO</i>
<i>Off</i>	<i>Defined by GPIO</i>

## ► HDD Activity

If this LED blinks, it indicates data access activities; otherwise, it remains off.

<i>Blinking Amber</i>	<i>Data access activity</i>
<i>Off</i>	<i>No data access activity</i>



## ► Link Activity

<i>Blinking Amber</i>	<i>Link has been established and there is activity on this port</i>
<i>Solid Amber</i>	<i>Link has been established and there is no activity on this port</i>
<i>Off</i>	<i>No link is established</i>

## ► Speed


<i>Solid Amber</i>	<i>Operating as a Gigabit connection (1000 Mbps)</i>
<i>Solid Green</i>	<i>Operating as a 100-Mbps connection</i>
<i>Off</i>	<i>Operating as a 10-Mbps connection</i>

## APPENDIX B: DUAL BIOS INTRODUCTION

Failure when booting up BIOS is not uncommon and can occur most often during a power failure, a mishandled BIOS update, a malware attack resulting in data corruption. When it happens, recovering procedures consume considerable time and effort. Lanner understands this pain and have empowered our products with the Dual BIOS feature.

### How Dual BIOS Works

Dual BIOS features two physical BIOS ROMs soldered onto the motherboard, carrying two separate BIOS images. If the Primary BIOS (default) is not functioning correctly and fails to respond within seconds (~25 seconds to 2 minutes, depend upon appliance), the system will invoke a bootup from the Secondary BIOS, automatically restarting the system and launch the operating system.



### 2nd Gen Dual BIOS

To provide increased flexibility and usage protection, Lanner has released the 2nd Gen Dual BIOS function on Lanner appliances. With 2nd Gen Dual BIOS, both the primary BIOS and secondary BIOS can be updated and flashed using the BIOS Tool to run different versions of BIOS ROMs independently for maximum compatibility. This additionally allow users to switch BIOS ROMs for booting up, toggling between primary BIOS and secondary BIOS.

- **Flexible recovery timer control**

Users can designate the amount of time before recovery BIOS launch. The amount of time is no longer fixed to 7 minutes.

- **Flexible Dual BIOS ROMs control.**

Users can flash both the Primary BIOS and Secondary BIOS, thus run different versions of BIOS ROMs independently for maximum compatibility.

### • Flexible Dual BIOS ROMs switch

The 2nd Gen Dual BIOS allow users to choose one of the BIOS ROMS (Primary BIOS/Secondary BIOS) for booting up. Use software command prompt to toggle between Primary BIOS and Secondary BIOS.

	Gen1 Dual BIOS	Gen2 Dual BIOS
<b>Function</b>	Primary / Recovery 2 <sup>ND</sup> BIOS for recovery purpose	Primary / Secondary (Peer to Peer) Both BIOS can let the system work
<b>Detection Time</b>	7 min	Seconds (By platform design)
<b>2<sup>nd</sup> BIOS updated</b>	Only using the SPI facility	By BIOS tool command or SPI facility
<b>MAC/DMI</b>	Only for BIOS1	For both BIOS
<b>CPLD Interface</b>	GPIO	LPC or eSPI (By Platform)

Figure 1. Gen 1 vs Gen 2 Dual BIOS comparison chart

Few things can shut down a computer as completely as a corrupted BIOS. With Dual BIOS feature, you will be guaranteed to enter a healthy OS to perform thorough troubleshooting before the situation is irreparable.

### Get Ready for BIOS Update

Flashing a BIOS needs to be carefully completed, especially pertaining to a corrupted BIOS, which can lead to an unusable system if done incorrectly. To get ready for a BIOS update, acquire the following BIOS resources from Lanner technical support:

- Firmware and Flash Tool
- BIOS Engineering Spec

Before you start, make sure you select the correct firmware version, correct BIOS (Primary or Secondary) and go through the instructions for BIOS update in *BIOS Engineering Spec* thoroughly. If you cannot be certain if this version is correct for your system, please contact Lanner Technical Support.



#### Note:

1. Dual BIOS feature cannot work with BIOS Boot Guard function
2. To update BIOS, it is mandatory to have both BIOS updated first. This is to avoid both BIOS having ME code variations, which could lead to unexpected risk and errors.
3. When the system enters BIOS menu or Option ROM, the system will not reboot automatically.



#### Warning

DO NOT power off or reset the system during BIOS updating process.

#### Disclaimer

Under no circumstances will Lanner accept responsibility or liability for damages of any kind whatsoever resulting or arising directly or indirectly from a BIOS update.



# APPENDIX C: REDUNDANT POWER MODULE BEHAVIOR

**Define the Alarm and Mute behavior**

	Power Module Fail	Power Module Remove	Power Cord Remove
Buzzer	Alarm	Alarm	Alarm
Mute	Change back the Good PSU Module or Press the Mute Button	Put back the PSU Module or Press the Mute Button	Plug-in the Power cord or Press the Mute Button

**Define the sequence of the Power Module**

PSU Sequence	The detection is from the left to the right side , from the bottom to the top side
--------------	--

Example :




# APPENDIX D: FAN SEQUENCE

## Define the sequence of the FAN


**FAN Sequence**    The detection is from the left to the right side , from the bottom to the top side

Example:



# APPENDIX E: SMART POWER & RESET BUTTON

## Smart Power and Reset Button – Control by CPLD



## APPENDIX F: ESD/SURGE ENHANCEMENT

Electrostatic Discharge (ESD): IEC-61000-4-2	Contact Discharge	Air Discharge	STD
Level 1	±2 kV	±2 kV	
Level 2	±4 kV	±4 kV	4K Contact (Default)
Level 3	±6 kV	±8 kV	8K Air (Default)
Level 4 (TBD)	±8 kV	±15 kV	
			<b>STD</b>
Surge Immunity (LAN) IEC-61000-4-5	Test Level		
Level 0	25V		
Level 1	500V		
Level 2	1kV		V (Default for Power DM (L to N) Line to Line V (Default for LAN CM (S to G) Line to Ground
Level 3 (TBD)	2kV		V (Default for Power CM (L to G, N to G, L+N to G) Line to Ground
Level 4	4kV		
			<b>STD</b>
Electrical Fast Transient (EFT): IEC-61000-4-4			
Level 1	0.5kV		V (Default for LAN)
Level 2	1kV		V (Default for Power)
Level 3 (TBD)	2kV		
Level 4	4kV		

## APPENDIX G: TERMS AND CONDITIONS

### Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after service freight charges for goods returned to the user.
3. The buyer will pay for repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service", RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:
  - ▶ Improper or inadequate maintenance by the customer
  - ▶ Unauthorized modification, misuse, or reversed engineering of the product
  - ▶ Operation outside of the environmental specifications for the product.

### RMA Service

#### Requesting an RMA#

1. To obtain an RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
2. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
3. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
4. Mark the RMA# clearly on the box.



**Note:** Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.

## RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

<b>RMA No:</b>		Reasons to Return: <input type="checkbox"/> Repair(Please include failure details)	
		<input type="checkbox"/> Testing Purpose	
Company:		Contact Person:	
Phone No.		Purchased Date:	
Fax No.:		Applied Date:	
Return Shipping Address: _____			
Shipping by: <input type="checkbox"/> Air Freight <input type="checkbox"/> Sea <input type="checkbox"/> Express _____			
<input type="checkbox"/> Others: _____			
<b>Item</b>	<b>Model Name</b>	<b>Serial Number</b>	<b>Configuration</b>

Item	Problem Code	Failure Status

**\*Problem Code:**

01: D.O.A.	07: BIOS Problem	13: SCSI	19: DIO
02: Second Time R.M.A.	08: Keyboard Controller Fail	14: LPT Port	20: Buzzer
03: CMOS Data Lost	09: Cache RMA Problem	15: PS2	21: Shut Down
04: FDC Fail	10: Memory Socket Bad	16: LAN	22: Panel Fail
05: HDC Fail	11: Hang Up Software	17: COM Port	23: CRT Fail
06: Bad Slot	12: Out Look Damage	18: Watchdog Timer	24: Others (Pls specify)

**Request Party**

**Confirmed By Supplier**

\_\_\_\_\_  
Authorized Signature / Date

\_\_\_\_\_  
Authorized Signature / Date