

# Lanner

## Vehicle Computing

Rugged Platforms for Vehicles and Railway Computing

## R3S User Manual

Version: 2.0

Date of Release: 2024-07-17

## About this Document

This manual describes the overview of the various functionalities of this product, and the information you need to get it ready for operation. It is intended for those who are:

- responsible for installing, administering and troubleshooting this system or Information Technology professionals.
- assumed to be qualified in the servicing of computer equipment, such as professional system integrators, or service personnel and technicians.

## Icon Descriptions

The icons are used in the manual to serve as an indication of interest topics or important messages. Below is a description of these icons:



**Note or Information:** This mark indicates that there is a note of interest and is something that you should pay special attention to while using the product.



**Warning or Important:** This mark indicates that there is a caution or warning and it is something that could damage your property or product.

## Online Resources and Technical Support

To obtain additional documentation resources and software updates for your system, please visit the [Lanner Download Center](#). For certain categories of documents, please register for a Lanner Account at [Lanner's official website](#), in order to access published documents and downloadable resources.

In addition to contacting your distributor or sales representative, you could visit our [Lanner Technical Support](#), to fill in a support ticket to our technical support department.

## Copyright and Trademarks

This document is copyrighted © 2024. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

## Documentation Feedback

Your feedback is valuable to us, as it will help us continue to provide you with more accurate and relevant documentation. To provide any feedback, comments or to report an error, please email to [contact@lannerinc.com](mailto:contact@lannerinc.com). Thank you for your time.

## Contact Information

### Taiwan Corporate Headquarters

**Lanner Electronics Inc.**

7F, No.173, Sec.2, Datong Rd.  
Xizhi District, New Taipei City 22184,  
Taiwan

**立端科技股份有限公司**

221 新北市汐止區  
大同路二段 173 號 7 樓

T: +886-2-8692-6060

F: +886-2-8692-6101

E: [contact@lannerinc.com](mailto:contact@lannerinc.com)

### USA

**Lanner Electronics Inc.**

47790 Westinghouse Drive  
Fremont, CA 94539

T: +1-855-852-6637

F: +1-510-979-0689

E: [sales\\_us@lannerinc.com](mailto:sales_us@lannerinc.com)

### Europe

**Lanner Europe B.V.**

Wilhelmina van Pruysenweg 104  
2595 AN The Hague  
The Netherlands

T: +31 70 701 3256

E: [sales\\_eu@lannerinc.com](mailto:sales_eu@lannerinc.com)

### China

**Beijing L&S Lancom Platform Tech. Co., Ltd.**

Guodong LOFT 9 Layer No. 9 Huinan Road,  
Huilongguan Town, Changping District, Beijing  
102208 China

T: +86 010-82795600

F: +86 010-62963250

E: [service@ls-china.com.cn](mailto:service@ls-china.com.cn)

### Canada

**Lanner Electronics Canada Ltd**

3160A Orlando Drive

Mississauga, ON

L4V 1R5 Canada

T: +1 877-813-2132

F: +1 905-362-2369

E: [sales\\_ca@lannerinc.com](mailto:sales_ca@lannerinc.com)

## Acknowledgment

Intel® and Intel® Atom™ are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

### FCC Caution

- ▶ Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- ▶ This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



#### Note

1. An unshielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



#### Important

1. Operations in the 5.15-5.25GHz band are restricted to indoor usage only.
2. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

## Safety Guidelines

Follow these guidelines to ensure general safety:

- ▶ Keep the chassis area clear and dust-free during and after installation.
- ▶ Do not wear loose clothing or jewelry that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- ▶ Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- ▶ Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- ▶ Disconnect all power by turning off the power and unplugging the power cord before installing or removing a chassis or working near power supplies
- ▶ Do not work alone if potentially hazardous conditions exist.
- ▶ Never assume that power is disconnected from a circuit; always check the circuit.

## Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- ▶ Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- ▶ Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- ▶ Portez des lunettes de sécurité pour protéger vos yeux.
- ▶ N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
- ▶ Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- ▶ Ne travaillez pas seul si des conditions dangereuses sont présentes.
- ▶ Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

## Lithium Battery Caution

- ▶ There is risk of Explosion if Battery is replaced by an incorrect type.
- ▶ Dispose of used batteries according to the instructions.
- ▶ Installation only by a skilled person who knows all Installation and Device Specifications which are to be applied.
- ▶ Do not carry the handle of power supplies when moving to another place.
- ▶ Please conform to your local laws and regulations regarding safe disposal of lithium BATTERY.
- ▶ Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion.
- ▶ Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas.
- ▶ A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

## Avertissement concernant la pile au lithium

- ▶ Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- ▶ Jetez les piles usagées conformément aux instructions.
- ▶ L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- ▶ Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.

## Operating Safety

- ▶ Electrical equipment generates heat. Ambient air temperature may not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Be sure that the room in which you choose to operate your system has adequate air circulation.
- ▶ Ensure that the chassis cover is secure. The chassis design allows cooling air to circulate effectively. An open chassis permits air leaks, which may interrupt and redirect the flow of cooling air from internal components.
- ▶ Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures. Be sure to follow ESD-prevention procedures when removing and replacing components to avoid these problems.
- ▶ Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. If no wrist strap is available, ground yourself by touching the metal part of the chassis.
- ▶ Periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohms).

## Sécurité de fonctionnement

- ▶ L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.
- ▶ Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- ▶ Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.
- ▶ Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.
- ▶ Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

## Mounting Installation Precaution

The following should be put into consideration for rackmount or similar mounting installations:

- ▶ Do not install and/or operate this unit in any place that flammable objects are stored or used in.
- ▶ The installation of this product must be performed by trained specialists; otherwise, a non-specialist might create the risk of the system's falling to the ground or other damages.
- ▶ Lanner Electronics Inc. shall not be held liable for any losses resulting from insufficient strength for supporting the system or use of inappropriate installation components.
- ▶ Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T<sub>ma</sub>) specified by the manufacturer.
- ▶ Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.
- ▶ Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- ▶ Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

- ▶ Reliable Grounding - Reliable grounding of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

### Installation & Operation :

- ▶ This equipment must be grounded. The power cord for product should be connected to a socket-outlet with earthing connection.  
Cet équipement doit être mis à la terre. La fiche d'alimentation doit être connectée à une prise de terre correctement câblée
- ▶ Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.  
Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.
- ▶ The machine can only be used in a restricted access location and must be installed by a skilled person.  
Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.
- ▶ This product is intended to be supplied by a Listed Power Adapter or DC power source, rated 12-24Vdc, 17.5-8A minimum, Tma = 70°C, and the altitude of operation = 5000m.

## Electrical Safety Instructions


Before turning on the device, ground the grounding cable of the equipment. Proper grounding (grounding) is very important to protect the equipment against the harmful effects of external noise and to reduce the risk of electrocution in the event of a lightning strike. To uninstall the equipment, disconnect the ground wire after turning off the power. A ground wire is required and the part connecting the conductor must be greater than 4 mm<sup>2</sup> or 10 AWG.

## Consignes de sécurité électrique

- ▶ Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- ▶ Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- ▶ Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- ▶ Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 4 mm<sup>2</sup> ou 10 AWG.


## Grounding Procedure for Power Source

- ▶ Loosen the screw of the earthing point.
- ▶ Connect the grounding cable to the ground.
- ▶ The protection device for the power source must provide 30 A current.
- ▶ This protection device must be connected to the power source before power.
- ▶ The cable should be 16 AWG



## Procédure de mise à la terre pour source d'alimentation

- ▶ Desserrez la vis du terminal de mise à la terre.
- ▶ Branchez le câble de mise à la terre à la terre.
- ▶ L'appareil de protection pour la source d'alimentation doit fournir 30 A de courant.
- ▶ Cet appareil de protection doit être branché à la source d'alimentation avant l'alimentation.
- ▶ Le câble doit être 16 AWG



# Table of Contents

---

<b>Chapter 1: Product Overview .....</b>	<b>9</b>
Ordering Information .....	9
System Specifications .....	9
Front Panel .....	11
Rear Panel .....	12
Motherboard Information.....	14
<b>Chapter 2: Hardware Setup .....</b>	<b>17</b>
Open the Chassis .....	22
Installing the M.2 LTE Module .....	23
Hard Disk Installation .....	24
<b>Chapter 3: Software Setup .....</b>	<b>25</b>
BIOS Setup .....	25
Advanced Page .....	27
IntelRCSetup.....	42
Security.....	46
Boot Menu.....	47
Save and Exit Menu .....	48
<b>Appendix A: LED Indicator Explanations .....</b>	<b>50</b>
<b>Appendix B: Ignition Control Setup .....</b>	<b>51</b>
<b>Appendix C: Terms and Conditions .....</b>	<b>55</b>


## CHAPTER 1: PRODUCT OVERVIEW

Built for rolling stock setting, the R3S series is certified with EN50155, EN50121-3-2, EN50121-4, EN50125-3 and EN45545 standard as an IP50 rated fan-less rolling stock computer. R3S not only features high-performance Intel Atom x7-E3950 CPU, but also boasts an abundance of I/O and internal expansion capabilities, including 6x M12 X-coded PoE/ PoE+ ports, 1x Removable 2.5" drive bay, 2x COM, dual HDMI, 4x USB 2.0 and 4x DI/DO ports, making it perfect for rolling stock control and monitoring, infotainment, video surveillance, and fleet management.

### Package Content

Your package contains the following items:

- ▶ 1x R3S Vehicle and Railway Computer



**Note:** If you should find any components missing or damaged, please contact your dealer immediately for assistance.

### Ordering Information

SKU No.	Description
R3SB	Intel Atom™ x7-E3950 Processor, 6x M12 X-coded IEEE 802.3af PoE port (any 3 ports support IEEE 802.3at PoE+), 2x M.2 3042 B key socket with dual SIM each, +9~50Vdc power input
R3SC	Intel Atom™ x7-E3950 Processor ,6x M12 X-coded IEEE 802.3af PoE port (any 3 ports support IEEE 802.3at PoE+) 2x M.2 3042 B key socket with dual SIM each, +43~154Vdc power input

### Optional Accessories




Model	Description
080W000707000	Power Cable M12, 5P, 20cm, 180°-180° TIMYN TM-18L-CABLE-5F-20-N

## System Specifications

<b>Platform</b>	CPU	Intel Apollo Lake x7-E3950 1.6G 12W
	Frequency	1.6 GHz
	BIOS	AMI SPI Flash BIOS
	Chipset	SoC
<b>Fanless</b>		Yes
<b>Memory</b>	Technology	LPDDR4 2133MHz
	Max. Capacity	Up to 8GB (Factory default: 8GB pre-populated)
	Socket	Memory Down
<b>Ethernet</b>	Controller	6x Intel i210IT
	Speed	10/100/1000 Mbps
	PoE	IEEE 802.3af/IEEE 802.3at; under maximum 90W power budget
	Interface	M12 X-coded
<b>Storage</b>	Type	1x Removable 2.5" drive bay (HDD/SSD not included)
<b>I/O</b>	Display Port	2x HDMI, 3840x2160 resolution
	PoE Port	6x IEEE 802.3af standard PoE (any 3 ports support IEEE 802.3at PoE+); under maximum 90W power budget
	Audio	Mic-in and Line-out with 2-watt by HD Audio
	Serial I/O Port	COM1: RS-232/422/485; COM2: RS-232/422/485; COM3: RS-232/CAN (default RS-232 TX/RX only)
	GPS	u-blox NEO-M8N; 3 GNSS (GPS, Galileo, GLONASS, BeiDou), default @ GPS + GLONASS dual band
	G-sensor	ADXL 345
	CAN Port	(Optional) 1x CAN Bus J1939 / J1708
	Digital I/O	12x DI 12V TTL Selectable and 4x DO 12V Level TTL; 2x 12V with 1A dry relay
	USB Port	4x USB 2.0 Type A
<b>Expansion Interface</b>	Antenna	5x SMA antenna hole (includes GPS+GLONASS x1)
	PCIe/USB	2x M.2 3042 B-Key
<b>Cooling</b>	Processor	Passive CPU heatsink
	System	Fanless design with corrugated aluminum
<b>Power</b>	Connector	5-pin M12 K-coded (Ground, DC_IN, Ground, IGN, Chassis Ground)
	Input	SKU B: Input Rated: +9~50Vdc SKU C: Input Rated: +43~154Vdc
	Output	12V/1A DC out
<b>Environment</b>	Operating Temperature	-40~70°C / -40~158°F (85°C for 10 minutes)
	Storage Temperature	-40~85°C / -40~185°F
	Relative Humidity	5%~95% @ 40°C / 104°F (Storage Level)
<b>Mechanical</b>	Dimension (W x H x D)	272.4 x 114.3 x 228mm (10.72" x 4.5" x 8.97")
	Weight	7 kg
	Mounting	Wall mount kit
<b>Driver Support</b>	Microsoft Windows	Win10 IoT
	Linux	Redhat Enterprise 5, Fedora 14, Linux Kernel 2.6.18 or later
<b>Certification</b>	EMC	FCC/CE Class A, RoHS
	Safety	E-13 include ISO-7637-2
	Certified	IP rated 50, MIL-STD-810G, EN50155, EN50121-3-2, EN50121-4, EN50125-3, EN 45545

## Front Panel






No.	Description																							
F1	LED Indicator		<div>System Power</div> <div>System Status</div> <div>HDD Status</div>																					
F2	USB 2.0 Port	4x USB 2.0 Type A																						
F3	Console Port	1x RS-232 (RJ45 connector)																						
		<table><tr><th>Pin</th><th>Signals</th><th>Pin</th><th>Signals</th></tr><tr><td>1</td><td>COM_RTS1#</td><td>2</td><td>COM_DTR1#</td></tr><tr><td>3</td><td>COM_SOUT1</td><td>4</td><td>GND_COM</td></tr><tr><td>5</td><td>GND_COM</td><td>6</td><td>COM_SIN1</td></tr><tr><td>7</td><td>COM_DSR1#</td><td>8</td><td>COM_CTS1#</td></tr></table>	Pin	Signals	Pin	Signals	1	COM_RTS1#	2	COM_DTR1#	3	COM_SOUT1	4	GND_COM	5	GND_COM	6	COM_SIN1	7	COM_DSR1#	8	COM_CTS1#		
	Pin	Signals	Pin	Signals																				
1	COM_RTS1#	2	COM_DTR1#																					
3	COM_SOUT1	4	GND_COM																					
5	GND_COM	6	COM_SIN1																					
7	COM_DSR1#	8	COM_CTS1#																					
F4	SIM Card Cover	4x SIM card slot																						
F5	Storage Lock	Lock for removable 2.5" storage caddy																						
F6	Antenna Port	<div><div>LTE Antenna</div><div>WiFi Antenna</div></div>																						
F7	Storage Bay	1x SATA interface storage bay to support removable 2.5" HDD/SSD drive bay																						

## Rear Panel



**Grounding Point:**

For safety measures to help prevent people from accidentally coming in contact with electrical hazards.

No.	Description																						
R1	PoE Port 	6x M12 X-coded 8-pin PoE/ PoE+ Port																					
		<table><tr><th>Pin</th><th>Signals</th><th>Pin</th><th>Signals</th></tr><tr><td>1</td><td>LANx*_MX0P</td><td>2</td><td>LANx*_MX0N</td></tr><tr><td>3</td><td>LANx*_MX1P</td><td>4</td><td>LANx*_MX1N</td></tr><tr><td>5</td><td>LANx*_MX3P</td><td>6</td><td>LANx*_MX3N</td></tr><tr><td>7</td><td>LANx*_MX2N</td><td>8</td><td>LANx*_MX2P</td></tr></table>	Pin	Signals	Pin	Signals	1	LANx*_MX0P	2	LANx*_MX0N	3	LANx*_MX1P	4	LANx*_MX1N	5	LANx*_MX3P	6	LANx*_MX3N	7	LANx*_MX2N	8	LANx*_MX2P	
Pin	Signals	Pin	Signals																				
1	LANx*_MX0P	2	LANx*_MX0N																				
3	LANx*_MX1P	4	LANx*_MX1N																				
5	LANx*_MX3P	6	LANx*_MX3N																				
7	LANx*_MX2N	8	LANx*_MX2P																				
R2	DC Input 	1x M12 K-coded 5-pin for power source, (Ground, DC_IN, Ground, IGN, Chassis Ground) R3SB: Input Rated: 24~36Vdc, R3SC: Input Rated: 72~110Vdc																					
		<table><tr><th>Pin</th><th>Signals</th><th>Pin</th><th>Signals</th></tr><tr><td>1</td><td>GND</td><td>2</td><td>DC-VIN</td></tr><tr><td>3</td><td>MCU_PG</td><td>4</td><td>IGN_IN</td></tr><tr><td>5(PE)</td><td>Chassis_GND</td><td></td><td></td></tr></table>	Pin	Signals	Pin	Signals	1	GND	2	DC-VIN	3	MCU_PG	4	IGN_IN	5(PE)	Chassis_GND							
Pin	Signals	Pin	Signals																				
1	GND	2	DC-VIN																				
3	MCU_PG	4	IGN_IN																				
5(PE)	Chassis_GND																						
R3	DC Output 	1x M12 A-coded 5-pin for DC 12V power output																					
		<table><tr><th>Pin</th><th>Signals</th><th>Pin</th><th>Signals</th></tr><tr><td>1</td><td>12V_Output</td><td>2</td><td>FORWARD</td></tr><tr><td>3</td><td>SPEED</td><td>4</td><td>12V_GND</td></tr><tr><td>5</td><td>GPS_GND</td><td></td><td></td></tr></table>	Pin	Signals	Pin	Signals	1	12V_Output	2	FORWARD	3	SPEED	4	12V_GND	5	GPS_GND							
Pin	Signals	Pin	Signals																				
1	12V_Output	2	FORWARD																				
3	SPEED	4	12V_GND																				
5	GPS_GND																						
R4	HDMI Port	2x HDMI Connector																					
R5	Antenna Port (GPS+GLONASS default)	1x 3 GNSS (GPS, Galileo, GLONASS, BeiDou) antenna support (G-sensor has no antenna needed)																					

R6

COM Port




2x DB9 Male Connector for RS232/422/485

Pin	Signals	Pin	Signals
1_up	COM2_C_DCD_TN	2_up	COM2_C_RXD_TP
3_up	COM2_C_TXD_RP	4_up	COM2_C_DTR_RN
5_up	GND_COM	6_up	COM2_C_DSR
7_up	COM2_C_RTS	8_up	COM2_C_CTS
9_up	COM2_C_RI		
1_down	COM3_C_DCD_TN	2_down	COM3_C_RXD_TP
3_down	COM3_C_TXD_RP	4_down	COM3_C_DTR_RN
5_down	GND_COM	6_down	COM3_C_DSR
7_down	COM3_C_RTS	8_down	COM3_C_CTS
9_down	COM3_C_RI		

R7

DI/DO Port




12x DI 12V TTL selectable, 4x DO 12V Level TTL,  
2x 12V with 1A dry relay

Pin	Signals	Pin	Signals
1_up	DI_1	2_up	DI_3
3_up	DI_5	4_up	DI_7
5_up	DI_9	6_up	DI_2
7_up	DI_4	8_up	DI_6
9_up	DI_8		
1_down	DO_0	2_down	DO_2
3_down	DI_COM	4_down	DI_0
5_down	DI_10	6_down	DO_1
7_down	DO_3	8_down	DGIN_0
9_down	DI_11		

R8

Audio Port




1x TSI HD Codec 92HD73C1T5PRGIC1X, supports external Audio I/O  
for Line-in/Line-out with L/R-channels via 9-pin female connector

Pin	Signals	Pin	Signals
1_down	RELAY1_COMM	2_down	RELAY2_COMM
3_down	GND_AUD	4_down	FRONT_OUT_R
5_down	FRONT_OUT_L	6_down	RELAY1_NOPEN
7_down	RELAY2_NOPEN	8_down	MIC_IN_R
9_down	MIC_IN_L		

R9

COM/CAN Port



COM/Optional CAN


Pin	Signals	Pin	Signals
1_up	J1850-/J1708-_L	2_up	GND_C/L
3_up	J1939+/L	4_up	K_LINE_L
5_up	CAN_L/J1939-_L	6_up	J1850-/J1708-_L
7_up	J1850+/J1708+_L	8_up	J1850+/J1708+_L
9_up	POWER (12V or 24V)		




## Motherboard Layout

The motherboard layout shows the connectors and jumpers on the board. Refer to the following picture as a reference for the pin assignments and the internal connectors.

### Front




## Rear



## Jumper Setting and Internal Connector

### BAT1

Pin	Signals
1	VBAT
2	GND



### BAT2

Pin	Signals
1	VBAT
2	GND




### LPC1

Pin	Signals	Pin	Signals
1	L_CLKOUT1	6	P3V3
2	LPC_AD1	7	LPC_AD3
3	PLTRST_BUF2	8	NC
4	LPC_ADD	9	LPC_AD2
5	L_FRAME_N	10	GND




### JSPI1

Pin	Signals	Pin	Signals
1	SPIO_HOLD_N	2	NC
3	SPIO_CS_N	4	V1P8_A_SPI
5	SPIO_MISO	6	NC
7	NC	8	SPIO_CLK
9	GND	10	SPIO_MOSI




### JCOMS1

Pin	Signals
1	NC
2	VCCRTC_3P3
3	GND




### JCOMS2

Pin	Signals
1	NC
2	RTEST_N
3	GND




### J2(for PMIC debug)

Pin	Signals
1	PMIC_SDA
2	PMIC_SCL
3	GND



### J3(for straps option)

Pin	Signals
1	SOC_COM2_TXD
2	V1P8_A




### SATAPWR1

Pin	Signals
1	12V
2	GND
3	GND
4	5V




### SATA1

Pin	Signals
1	GMD
2	TX+
3	TX-
4	GND
5	RX-
6	RX+
7	GND




### JCOM1(for MCU)

Pin	Signals
1	P3V3
2	SYS_RXD
3	SYS_TXD
4	GND




### JCOM2(for power MCU)

Pin	Signals
1	IGN3V3_SB
2	MCU_RXD
3	MCU_TXD
4	GND




### J4(for power MCU)

Pin	Signals
1	IGN3V3_SB
2	P_PID0_1
3	GND_PRI




### HDD\_LOCK1

Pin	Signals
1	HDD_LOCK#
2	GND



### SW1(for MCU)

Pin	Signals	Pin	Signals
1	PIO1_6_RXD	12	SOUT6
2	PIO1_7_TXD	11	SIN6
3	PIO1_6_RXD	10	SYS_RXD
4	PIO1_7_TXD	9	SYS_TXD
5	NC	8	NC
6	PIO0_1	7	GND




- 1 ☐ 12
- 2 ☐ 11
- 3 ☐ 10
- 4 ☐ 9
- 5 ☐ 8
- 6 ☐ 7

**MSATA1**

Pin	Description	Pin	Description
1	N.C	2	+3.3V
3	N.C	4	GND
5	N.C	6	N.C
7	N.C	8	N.C
9	GND	10	N.C
11	N.C	12	N.C
13	N.C	14	N.C
15	GND	16	N.C
KEY			
17	N.C	18	GND
19	N.C	20	N.C
21	GND	22	N.C
23	SATA RX <sub>p</sub>	24	+3.3V
25	SATA RX <sub>n</sub>	26	GND
27	GND	28	N.C
29	GND	30	N.C
31	SATA TX <sub>n</sub>	32	N.C
33	SATA TX <sub>p</sub>	34	GND
35	GND	36	N.C
37	GND	38	N.C
39	+3.3V	40	GND
41	+3.3V	42	N.C
43	N.C	44	N.C
45	N.C	46	N.C
47	N.C	48	N.C
49	N.C	50	GND
51	N.C	51	+3.3V

**M2\_1 & M2\_2 (B KEY)**

Pin	Description	Pin	Description
1	GND	2	3V3 AUX
3	GND	4	3V3 AUX
5	GND	6	F CARD PWROFF#
7	USB2_D-	8	W_DIS#
9	USB2_D+	10	LED#/1DAS/DSS#
11	GND	12	NOTCH5
13	NOTCH1	14	NOTCH6
15	NOTCH2	16	NOTCH7
17	NOTCH3	18	NOTCH8
19	NOTCH4	20	AUDIO 0
21	GND_WWAN/OC-SSD	22	AUDIO 1
23	NC	24	AUDIO 2
25	NC	26	AUDIO 3
27	GND	28	UIM RFU
29	PERn1/USB3TX-	30	UIM_RESET
31	PERp1/USB3TX+	32	UIM_CLK
33	GND	34	UIM_DATA
35	PETn1/USB3TX-	36	UIM_PWR
37	PETp1/USB3TX+	38	DEVSLP
39	GND	40	GNSS0
41	NC	42	GNSS1
43	NC	44	GNSS2
45	GND	46	GNSS3
47	NC	48	GNSS4
49	NC	50	PERST#
51	GND	52	CLKREO#
53	REFCLKN	54	WAKE#
55	REFCLKP	56	NC
57	GND	58	NC
59	ANTCTL0	60	COEX3
61	ANTCTL1	62	COEX2
63	ANTCTL2	64	COEX1
65	ANTCTL3	66	SIM_DET
67	RESET#	68	SUSCLK
69	PEDET	70	3V3_AUX
71	GND	72	3V3_AUX
73	GND	74	3V3_AUX
75	OC-USB3/GND-OTHER		



**MIO1**

Pin	Signals	Pin	Signals
1~18	GND	51~68	GND
19	HAD_RST#	69	GND
20	GND	70	GND
21	HAD_BLK	71	GND
22	GND	72	GND
23	HDA_SDO	73	PLTRST_BUF2_N
24	HAD_SYNC	74	GND
25	HAD_SDIO	75	MCU_CLK_R
26	GND	76	MCU_DAT_R
27	COM2_M0	77	GND
28	COM2_M1	78	COM3_MO
29	COM2_TERM	79	COM3_M1
30	DCD2#	80	COM3_TERM
31	RI2#	81	DCD3#
32	CTS2#	82	RI3#
33	DTR2#	83	CTS3#
34	RTS2#	84	DTR3#
35	DSR#2	85	DSR3#
36	SOUT2	86	SIN3
37	SIN2	87	SOUT3
38	GND	88	RTS3#
39	IGN_DI0	89	GND
40	GND	90	SOUT5
41	GND	91	SIN5
42	V3P3_A	92	GND
43	V3P3_A	93	RELAY1_EN
44	V3P3_A	94	RELAY2_EN
45	V3P3_A	95	GND
46	GND	96	V3P3_S
47	V1P8_S	97	V3P3_S
48	V1P8_S	98	V3P3_S
49	V1P8_S	99	V3P3_S
50	V1P8_S	100	GND


**MIO2**

Pin	Signals	Pin	Signals
1	NC	21	VPORT_OUT6
2	NC	22	POE_GND
3	NC	23	POE_GND
4	NC	24	VPORT_OUT5
5	NC	25	POE_GND
6	NC	26	POE_GND
7	NC	27	VPORT_OUT4
8	NC	28	POE_GND
9	NC	29	POE_GND
10	NC	30	VPORT_OUT3
11	NC	31	POE_GND
12	NC	32	POE_GND
13	NC	33	VPORT_OUT2
14	NC	34	POE_GND
15	NC	35	POE_GND
16	NC	36	VPORT_OUT1
17	NC	37	POE_GND
18	NC	38	V_LED
19	NC	39	POE_GND
20	NC	40	VEE




## Motherboard Layout (RI03SB1)

### ◆ Front




### ◆ Rear



## Jumper setting and Internal Connector (RI03SB1)


### SW1

Pin	Signals	Pin	Signals
1	SIO_SOUT5	8	J1939+
2	SIO_SIN5	7	GND_C
3	CAN_H/J1939+ _L	6	J1939+
4	GND_CAN	5	GND_C




### CN1

Pin	Signals	Pin	Signals
1		2	K_LINE
3	DO	4	NC
5	GND_CANL	6	GND_CANL
7	NC	8	J1850+/J1708+
9	SIO_SIN5	10	J1850-/J1708-
11	SIO_SOUT5	12	CAN_H/J1939+ _L
13	P5V	14	CAN_L/J1939-




### JR11

Pin	Signals	Pin	Signals
1	COM1_C_RI	2	COM_RI1#SEL
3	VCC5_ISO1_2	4	COM_RI1#SEL



### JR12

Pin	Signals	Pin	Signals
1	COM2_C_RI	2	COM_RI2#SEL
3	VCC5_ISO1_2	4	COM_RI2#SEL



### MIO1

Pin	Signals	Pin	Signals
1~18	GND	51~68	GND
19	HAD_RST#	69	GND
20	GND	70	GND
21	HAD_BLK	71	GND
22	GND	72	GND
23	HDA_SDO	73	PLTRST_BUF2 N
24	HAD_SYNC	74	GND
25	HAD_SDIO	75	MCU_CLK_R
26	GND	76	MCU_DAT_R
27	COM2_M0	77	GND
28	COM2_M1	78	COM3_M0
29	COM2_TERM	79	COM3_M1
30	DCD2#	80	COM3_TERM
31	RI2#	81	DCD3#
32	CTS2#	82	RI3#
33	DTR2#	83	CTS3#
34	RTS2#	84	DTR3#
35	DSR#2	85	DSR3#
36	SOUT2	86	SIN3
37	SIN2	87	SOUT3
38	GND	88	RTS3#
39	IGN_DI0	89	GND
40	GND	90	SOUT5
41	GND	91	SIN5
42	V3P3_A	92	GND
43	V3P3_A	93	RELAY1_EN
44	V3P3_A	94	RELAY2_EN
46	GND	96	V3P3_S
47	VIP8 S	97	V3P3_S
48	VIP8 S	98	V3P3_S
49	V1P8 S	99	V3P3_S
50	V1P& S	100	GND



### MIO2

Pin	Signals	Pin	Signals
1	NC	21	VPORT_OUT6
2	NC	22	POE_GND
3	NC	23	POE_GND
4	NC	24	VPORT_OUT5
5	NC	25	POE_GND
6	NC	26	POE_GND
7	NC	27	VPORT_OUT4
8	NC	28	POE_GND
9	NC	29	POE_GND
10	NC	30	VPORT_OUT3
11	NC	31	POE_GND
12	NC	32	POE_GND
13	NC	33	VPORT_OUT2
14	NC	34	POE_GND
15	NC	35	POE_GND
16	NC	36	VPORT_OUT1
17	NC	37	POE_GND
18	NC	38	V_LED
19	NC	39	POE_GND
20	NC	40	VEE



## CHAPTER 2: HARDWARE SETUP

To reduce the risk of personal injury, electric shock, or damage to the unit, please remove all power connections to completely shut down the device. Also, please wear ESD protection gloves when conducting the steps in this chapter.

### Open the Chassis

For installation of the M.2 LTE and mSATA storage, please remove the HDD tray and tilt down the device and remove screw on the front/back and two sides as below:




Lift up the chassis and remove the indicated screws that secure the board onto the standoffs



## Installing the M.2 LTE Module

1. Locate **M.2** slot. Align the notch of the module with the socket key in the slot, and insert it at 30 degrees into the socket until it is fully seated in the connector.
2. Push down on the module and secure it with the screw that comes with it.
3. To install the SIM cards, on front panel, loosen the screw that secures the cover onto the system.
4. Push the SIM cards into the socket. Make sure the angled corner of the card is correctly positioned.
5. To remove the card, simply push it to have it bounce out automatically.



## Hard Disk Installation

To install the hard disk,


1. Loosen the two hand screws that secure the hard disk tray.
2. Pull out the tray as shown in the picture below.




3. Remove the screws shown in the picture.



4. Open the tray and install the disk onto the tray.



5. Connect the SATA cable and lock the drive in-place with screws.  
Reverse Step 1 ~ Step 3 to lock the disk tray back into the chassis.



## CHAPTER 3: SOFTWARE SETUP

### BIOS Setup

BIOS is a firmware embedded on an exclusive chip on the system's motherboard. Lanner's BIOS firmware offering including market-proven technologies such as Secure Boot and Intel Boot Guard technology deliver solid commitments for the shield protection against malware, uncertified sequences and other named cyber threats.


#### Main Page Setup

To enter the BIOS setup utility, simply follow the steps below:

1. Boot up the system.
2. Pressing the **<Esc>** or **<Del>** key immediately allows you to enter the Setup utility, and then you will be directed to the BIOS main screen. The instructions for BIOS navigations are as below:

Control Keys	Description
→←	select a setup screen
↑↓	select an item/option on a setup screen
<Enter>	select an item/option or enter a sub-menu
+/-	adjust values for the selected setup item/option
F1	display General Help screen
F2	retrieve previous values, such as the last configured parameters during the last time you entered BIOS
F3	load optimized default values
F4	save configurations and exit BIOS
<Esc>	exit the current screen


Setup main page contains BIOS information and project version information.



Feature	Description
BIOS Information	BIOS Vendor: American Megatrends Core Version: AMI Kernel version, CRB code base, X64 Compliance: UEFI version, PI version Project Version: BIOS release version Build Date and Time: MM/DD/YYYY Access Level: Administrator / User
System Date	To set the Date, use <b>&lt;Tab&gt;</b> to switch between Date elements. Default Range of Year: 2005-2099 Default Range of Month: 1-12 Days: dependent on Month.
System Time	To set the Date, use <b>&lt;Tab&gt;</b> to switch between Date elements.

## Advanced Page

Select the **Advanced** menu item from the BIOS setup screen to enter the “Advanced” setup screen. Users can select any of the items in the left frame of the screen.




## Super IO Configuration

```

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.
  Advanced
/-----\
| Super IO Configuration                                |Set Parameters of|
|                                                        |Serial Port 1 (COMA)|
|> Serial Port 1 Configuration                          |                  |
|> Serial Port 2 Configuration                          |                  |
|> Serial Port 3 Configuration                          |                  |
|> Serial Port 4 Configuration                          |                  |
|> Serial Port 5 Configuration                          |                  |
|> Serial Port 6 Configuration                          |                  |
|                                                        |                  |
|                                                        |-----\
|                                                        |>: Select Screen  |
|                                                        |^v: Select Item   |
|                                                        |Enter: Select     |
|                                                        |+/-: Change Opt.  |
|                                                        |F1: General Help  |
|                                                        |F2: Previous Values|
|                                                        |F3: Optimized Defaults|
|                                                        |F4: Save & Exit    |
|                                                        |ESC: Exit          |
\-----/
Version 2.18.1263. Copyright (C) 2019 American Megatrends, Inc.

```

### ■ Serial port 1 ~ 2 Configuration




Feature	Options	Description
Serial Port	Enabled Disabled	Enables or disables Serial Port 1.
Device Settings	NA	IO=3F8h; IRQ = 4 → Serial Port 1 IO=2F8h; IRQ = 11 → Serial Port 2
COM mode	RS232 RS485 RS422	Configure COM port mode.

## ■ Serial port 3 ~ 6 Configuration


Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.		
Advanced		
Serial Port 3 Configuration		Enable or Disable Serial Port (COM)
Serial Port	[Enabled]	
Device Settings	IO=3E8h; IRQ=5;	
		>: Select Screen  ^v: Select Item  Enter: Select  +/-: Change Opt.  F1: General Help  F2: Previous Values  F3: Optimized Defaults  F4: Save & Exit  ESC: Exit
Version 2.18.1263. Copyright (C) 2019 American Megatrends, Inc.		
Feature	Options	Description
Serial Port	Enabled Disabled	Enables or disables Serial Port 3 ~ 6.
Device Settings	NA	Assigned to IO=3E8h; IRQ = 5

## ■ Hardware Monitor




Feature	Description
CPU Temp	This value reports the CPU temperature.
SYS Temp	This value reports the System temperature.
VCORE	This value reports the CPU VCORE.
Vddr	This value reports the Vddr.
VBAT	This value reports the VBAT Input voltage.
5V	This value reports the 5V Input voltage.
3V3	This value reports the 3.3V Input voltage.

## ■ Watch Dog Timer Configuration




Feature	Options	Description
Watch Dog Timer	Enabled Disabled	Enable or Disable Watch Dog function
Timer Count Mode	Second Mode Minute Mode	Select Second Mode or Minute Mode
Timer out Value	60	Watch Dog Timer out Value 0-255

## ■ SIM Selector Setting




Feature	Options	Description
SIM Selector1	SIM-1 SIM-2	Select which SIM card would use
SIM Selector2	SIM-3 SIM-4	Select which SIM card would use

## ■ Serial Port Console Redirection



Feature	Options	Description
COM0	Enabled	Console Redirection Enable or Disable.
Console Redirection	Disabled	


## ■ Console Redirection Setting



Feature	Options	Description
Terminal Type	VT100 VT100+ VT-UTF8 ANSI	ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Bits per second	9600 19200 38400 57600 115200	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
Data Bits	7 8	Data Bits
Parity	None Even Odd Mark Space	A parity bit can be sent with the data bits to detect some transmission errors.
Stop Bits	1	Stop bits indicate the end of a serial data packet.

	2	
Flow Control	None Hardware RTS/CTS	Flow control can prevent data loss from buffer overflow.
VT-UTF8 Combo Key Support	Disabled Enabled	Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Disabled Enabled	With this mode enabled only text will be sent. This is to capture Terminal data.
Resolution 100x31	Disabled Enabled	Enables or disables extended terminal resolution.
Putty KeyPad	VT100 LINUX XTERM86 SCO ESCN VT400	Select FunctionKey and KeyPad on Putty.

## ■ CPU Configuration




Feature	Options	Description
Intel Virtualization Technology	Disabled Enabled	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology
VT-d	Disabled Enabled	Enable/Disable CPU VT-d

## ■ Socket 0 CPU Information


Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.		
Advanced		
-----+-----		
Socket 0 CPU Information		
Intel(R) Atom(TM) Processor E3950 @ 1.60GHz		
CPU Signature	506CA	
Microcode Patch	16	
Max CPU Speed	1600 MHz	
Min CPU Speed	800 MHz	
Processor Cores	4	
Intel HT Technology	Not Supported	
Intel VT-x Technology	Supported	-----+-----
		><: Select Screen
L1 Data Cache	24 kB x 4	^v: Select Item
L1 Code Cache	32 kB x 4	Enter: Select
L2 Cache	1024 kB x 2	+/-: Change Opt.
L3 Cache	Not Present	F1: General Help
		F2: Previous Values
		F3: Optimized Defaults
		F4: Save & Exit
		ESC: Exit
-----+-----		
Version 2.18.1263. Copyright (C) 2019 American Megatrends, Inc.		

## ■ PCI Subsystem Settings




Feature	Options	Description
Above 4G Decoding	Disabled Enabled	Globally Enables or Disables 64bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64 bit PCI Decoding).
BME DMA Mitigation	Disabled Enabled	Re-enable Bus Master Attribute disabled during PCI enumeration for PCI bridge after SMM Locked.
Hot-Plug Support	Enabled Disabled	Globally Enables or Disables Hot-Plug support for the entire System. If System has Hot-Plug capable Slots and this option set to Enabled, it provides a Setup screen for selecting PCI resource padding for Hot-Plug.

## ■ CSM Configuration



Feature	Options	Description
CSM Support	Disabled <b>Enabled</b>	Enables or disables CSM Support
Network	Do Not Launch UEFI <b>Legacy</b>	Controls the execution of UEFI and Legacy PXE OpROM
Storage	Do Not Launch UEFI <b>Legacy</b>	Controls the execution of UEFI and Legacy Storage OpROM
Video	Do Not Launch UEFI <b>Legacy</b>	Controls the execution of UEFI and Legacy Video OpROM
Other PCI device	Do Not Launch UEFI <b>Legacy</b>	Determines OpROM execution policy for devices other than Network, Storage, or Video


## ■ USB Configuration




Feature	Options	Description
Legacy USB Support	Enabled Disabled Auto	Enables Legacy USB support. <b>Auto</b> option disables legacy support if no USB devices are connected; <b>Disabled</b> option will keep USB devices available only for EFI applications.
XHCI Hand-off	Enabled Disabled	This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enabled Disabled	Enables or disables USB Mass Storage Driver Support.
USB transfer time-out	1 sec / 5 sec 10 sec / 20 sec	The time-out value for Control, Bulk, and Interrupt transfers
Device reset time-out	1 sec / 5 sec 10 sec / 20 sec	USB mass storage device Start Unit command time-out
Device power-up delay	Auto Manual	Maximum time the device will take before it properly reports itself to the Host Controller. <b>Auto</b> uses default value: for a Root port, it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

## IntelRCSetup

Select the IntelRCSetup menu item from the BIOS setup screen to enter the Platform Setup screen. Users can select any of the items in the left frame of the screen.




## ■ North Bridge



Feature	Options	Description
Max TOLUD	2 GB	Maximum Value of TOLUD.
	2.25 GB	
	2.5 GB	
	2.75 GB	
	3 GB	


=

## ■ South Bridge




Feature	Options	Description
OS Selection	<b>Windows</b> Android Win7 Intel Linux	Select the target OS

## ■ South Cluster Configuration



## Security


Select the Security menu item from the BIOS setup screen to enter the Security Setup screen. Users can select any of the items in the left frame of the screen.



Feature	Description
Administrator Password	If ONLY the Administrator's password is set, it only limits access to Setup and is only asked for when entering Setup.
User Password	If ONLY the User's password is set, it serves as a power-on password and must be entered to boot or enter Setup. In Setup, the User will have Administrator rights.

## Boot Menu

Select the Boot menu item from the BIOS setup screen to enter the Boot Setup screen. Users can select any of the items in the left frame of the screen.




Feature	Options	Description
Setup Prompt Timeout	5	The number of seconds to wait for setup activation key. 65535 means indefinite waiting.
Bootup NumLock State	On Off	Select the keyboard NumLock state
Quiet Boot	Disabled Enabled	Enables or disables Quiet Boot option.
Boot mode select	LEGACY UEFI DUAL	Select boot mode for LEGACY or UEFI.

- Choose boot priority from boot option group.
- Choose specifies boot device priority sequence from available Group device.


## Save and Exit Menu

Select the Save and Exit menu item from the BIOS setup screen to enter the Save and Exit Setup screen. Users can select any of the items in the left frame of the screen.




### ■ Discard Changes and Exit

Select this option to quit Setup without saving any modifications to the system configuration. The following window will appear after the **"Discard Changes and Exit"** option is selected. Select **"Yes"** to Discard changes and Exit Setup.




### ■ Save Changes and Reset

When Users have completed the system configuration changes, select this option to save the changes and reset from BIOS Setup in order for the new system configuration parameters to take effect. The following window will appear after selecting the **"Save Changes and Reset"** option is selected. Select **"Yes"** to Save Changes and reset.



### ■ Restore Defaults

Restore default values for all setup options. Select **"Yes"** to load Optimized defaults.



PS: The items under Boot Override were not same with image. It should depend on devices connect on system.

## APPENDIX A: LED INDICATOR EXPLANATIONS

The status explanations of LED indicators on Front Panel are as follows:

### ▶ HDD Activity Status

<i>Blinking Amber</i>	<i>Data access activities</i>
<i>Off</i>	<i>No data access activities</i>

### ▶ System Power

<i>Solid Green</i>	<i>The system is powered on</i>
<i>Off</i>	<i>The system is powered off</i>

### ▶ LAN LED Status (LED1~LED6)

<i>Speed</i>	<i>Solid Green</i>	<i>100M link</i>
	<i>Solid Amber</i>	<i>1G link</i>
	<i>Off</i>	<i>10M/No activities</i>

<i>Link/Act</i>	<i>Solid Amber</i>	<i>link</i>
	<i>Blinking Amber</i>	<i>Active</i>
	<i>Off</i>	<i>No activities</i>



## APPENDIX B: IGNITION CONTROL SETUP

### Connecting the Devices

The system comes with a controller to ensure that the device is well-shielded against premature failure at the boot or shutdown phase. When installing:

1. Make sure both your vehicle and the system are turned off.
2. Follow the wiring definition and illustration below to connect the vehicle battery and ignition (ACC) to the in-vehicle system through the 5-pin M12 male connector marked as "DC Input" on the system, through the right pin contact.


In a typical in-vehicle computing solution, this system usually acts as a PSE (Power Sourcing Equipment) to power up connected PoE devices, for which you should ensure a minimum of 48V DC power supply to the system with the use of a **DC to DC Adapter**.



Pin1	Ground
Pin2	VCC
Pin3	GND_DCIN
Pin4	Ignition
PE	Chassis Ground

## Power States Cycle Diagram

The diagram below describes the cycle of system's power states controlled by the Ignition System Manager (ISM) when the appropriate timer control parameters are set.



**Note:** When the system's shutdown timer starts counting down 60sec, using ignition or External PWR\_BTN to start the system again during shutdown process will not work until the countdown finishes.

## Using the Ignition System Manager (ISM)

Command Format:

1. Host communication interface: COM#6 (RS-232)
2. Support baud rate: 57600/ 8N1
3. Communication protocol: ANSI terminal.

GET VariableName

SET VariableName value

MCU Command	Write/Read (SET/GET)	VariableName	value	
Startup Voltage(mV)	SET	STARTUP_VOLTAGE	0(default)	0mV
	GET	STARTUP_VOLTAGE		
Shutdown Voltage(mV)	SET	INPUT_VOLTAGE_MIN	0(default)	0mV
	GET	INPUT_VOLTAGE_MIN		
PowerOn Delay (Sec)	SET	POWERON_DELAY	4(default)	4S
	GET	POWERON_DELAY		
PowerOff Delay (Sec)	SET	SHUTDOWN_DELAY	4(default)	4S
	GET	SHUTDOWN_DELAY		
Input Voltage	GET	INPUT_VOLTAGE		
Wakeup DI1	SET	WAKEUP_ENABLE	7(default)	1:DI1 2:Reserved 4: Reserved
Device ID	GET	DEVICE_ID	R3S_N	
Firmware Version	GET	VERSION	0.06B	
Digital Out (SIM selection)	SET	DIGITAL_OUT	0(default)	
Digital In	GET	DIGITAL_IN		
Ignition	GET	IGNITION		
Digital POE	SET	DIGITAL_POE	63(default)	0~63
	GET	DIGITAL_POE		
Digital DO	SET	DIGITAL_DO	0(default)	0~15
Digital DI	GET	DIGITAL_DI		
Relay Switch	SET	RELAY_SWITCH	0(default)	0~3
	GET	RELAY_SWITCH		
Save flash	SAVE			

**Example:**

1. The minimum voltage for startup,  
Setting : 6V(6000mV)

Command	Response message
SET STARTUP_VOLTAGE 6000	OK
GET STARTUP_VOLTAGE	STARTUP_VOLTAGE= 6000

2. The delay time for POWERON\_DELAY state,  
Setting : 4 S

Command	Response message
SET POWERON_DELAY 4	OK
GET POWERON_DELAY	POWERON_DELAY= 4

3. Wakeup DI1 Enable,  
Setting : DI1 enable (001)

Command	Response message
SET WAKEUP_ENABLE 1	OK
GET WAKEUP_ENABLE	WAKEUP_ENABLE= 1

4. Device ID

Command	Response message
GET DEVICE_ID	DEVICE_ID= R3S_N

5. Firmware Version

Command	Response message
GET VERSION	VERSION= 0.06B

6. Write/Read Digital\_Out state,  
Setting : SIM Card Control

Command	Response message
SET DIGITAL_OUT 3	OK
GET DIGITAL_OUT	DIGITAL_OUT= 3

- bit0 = LTE 1(M.2) - SIM Control  
1: SIM #2  
0: SIM #1
- bit1 = LTE 2(M.2) - SIM Control  
1: SIM #1  
0: SIM #2
- bit2 = LTE 1(M.2) - Power Control  
1: Power Off  
0: Power On
- bit3 = LTE 2(M.2) - Power Control  
1: Power Off  
0: Power On

7. Read Digital\_In state

Command	Response message
GET DIGITAL_IN	DIGITAL_IN= 3

8. Ignition state (only read)

Command	Response message
GET IGNITION	IGNITION= 0 (0: Ignition off / 1: ignition on)

9. Control the ON/OFF of each POE port

Command	Response message
SET DIGITAL_POE 1	OK
GET DIGITAL_POE	DIGITAL_POE= 1

- POE1/bit0 = 1  
POE2/bit1 = 2  
POE3/bit2 = 4  
POE4/bit3 = 8  
POE5/bit4 = 16  
POE6/bit5 = 32

To achieve POE1~6 enable, please entry value setting at 63.

10. Write/Read Digital\_DO state,  
Setting : DO1、DO2、DO3、DO4

Command	Response message
SET DIGITAL_DO 3	OK
GET DIGITAL_DO	DIGITAL_DO= 3

- DO1/bit0 = 1  
DO2/bit1 = 2  
DO3/bit2 = 4  
DO4/bit3 = 8

To achieve DO1~4 enable, please entry value setting at 15.

11. Relay Control

Command	Response message
SET RELAY_SWITCH 1	OK
GET RELAY_SWITCH	RELAY_SWITCH= 1

- bit0 = Relay1 Control  
1: Enable  
0: Disable
- bit1 = Relay2 Control  
1: Enable  
0: Disable

12. Save setting

Command	Response message
SAVE	OK Flash Updated

## APPENDIX C: TERMS AND CONDITIONS

### Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after-service freight charges for goods returned to the user.
3. The buyer will pay for the repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service," RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:
  - ▶ Improper or inadequate maintenance by the customer
  - ▶ Unauthorized modification, misuse, or reversed engineering of the product
  - ▶ Operation outside of the environmental specifications for the product.

### RMA Service

#### Requesting an RMA#

1. To obtain an RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
2. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
3. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
4. Mark the RMA# clearly on the box.



**Note:** Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.

## RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

<b>RMA No:</b>	Reasons to Return: <input type="checkbox"/> Repair (Please describe failure details) <input type="checkbox"/> Testing Purpose
Company:	Contact Person:
Phone No.	Purchased Date:
Fax No.:	Apply Date:
Return Shipping Address: _____	
Shipping by: <input type="checkbox"/> Air Freight <input type="checkbox"/> Sea <input type="checkbox"/> Express: _____ <input type="checkbox"/> Others: _____	

Item	GP	Model Name	Serial Number	Configuration

Item	Problem Code	Failure Status

### \*Problem Code:

01: D.O.A.	07: BIOS Problem	13: SCSI	19: DIO
02: Second Time R.M.A.	08: Keyboard Controller Fail	14: LPT Port	20: Buzzer
03: CMOS Data Lost	09: Cache RMA Problem	15: PS2	21: Shut Down
04: FDC Fail	10: Memory Socket Bad	16: LAN	22: Panel Fail
05: HDC Fail	11: Hang Up Software	17: COM Port	23: CRT Fail
06: Bad Slot	12: Appearance Damage	18: Watchdog Timer	24: Others (Pls specify)

**Requested by**

**Confirmed by supplier**

\_\_\_\_\_  
Authorized Signature / Date

\_\_\_\_\_  
Authorized Signature / Date