

# Network Application Platforms

Hardware platforms for next generation networking infrastructure



## **FW-8893/FW-8893C V2.0**

User's Manual

>>

Publication date: 2014-07-17

## Overview

---

### Icon Descriptions

The icons are used in the manual to serve as an indication of interest topics or important messages. Below is a description of these icons:



**NOTE:** This check mark indicates that there is a note of interest and is something that you should pay special attention to while using the product.



**WARNING:** This exclamation point indicates that there is a caution or warning and it is something that could damage your property or product.

### Online Resources

The listed websites are links to the on-line product information and technical support.

Resource	Website
Lanner	<a href="http://www.lannerinc.com">http://www.lannerinc.com</a>
Product Resources	<a href="http://www.lannerinc.com/support/download-center">http://www.lannerinc.com/support/download-center</a>
RMA	<a href="http://eRMA.lannerinc.com">http://eRMA.lannerinc.com</a>

### Copyright and Trademarks

This document is copyrighted, © 2014. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

### Acknowledgement

Intel, Pentium and Celeron are registered trademarks of Intel Corp.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

### Compliances

#### CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

#### FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



## Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- Portez des lunettes de sécurité pour protéger vos yeux.
- N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
- 
- Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- Ne travaillez pas seul si des conditions dangereuses sont présentes.
- Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

## Avertissement concernant la pile au lithium

- Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- Jetez les piles usagées conformément aux instructions.
- L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.
- La machine ne peut être utilisée qu'à un lieu fixe comme en laboratoire, salle d'ordinateurs ou salle de classe.

## Sécurité de fonctionnement

- L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.
- Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.
  - Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.

Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

## Consignes de sécurité électrique

- Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 4 mm<sup>2</sup> ou 10 AWG.


## Procédure de mise à la terre pour source d'alimentation CC

### Procédure de mise à la terre pour source d'alimentation CC

- Desserrez la vis du terminal de mise à la terre.
- Branchez le câble de mise à la terre à la terre.
- L'appareil de protection pour la source d'alimentation CC doit fournir 30 A de courant.



Cet appareil de protection doit être branché à la source d'alimentation avant l'alimentation CC.



## Revision History

Revision	Revision Date	Changes
1.2	20131029	Add French version of safety guidelines
2.0	20140717	Add FW-8893C specifications



# Table of Contents

<b>Chapter 1: Introduction</b>	<b>1</b>
System Specification . . . . .	1
Package Contents . . . . .	2
Front Panel Features. . . . .	3
Rear Panel Features . . . . .	5
<b>Chapter 2: Hardware Setup</b>	<b>6</b>
Preparing the Hardware Installation. . . . .	6
Installing the System Memory . . . . .	6
Installing a CompactFlash Card. . . . .	7
CPU and the Heat Sink Installation. . . . .	7
Hard Disk Installation . . . . .	8
<b>Chapter 3: Motherboard Information</b>	<b>10</b>
Block Diagram . . . . .	10
Motherboard Layout . . . . .	11
Jumper Settings . . . . .	12
<b>Chapter 4: BIOS Settings</b>	<b>16</b>
Updating the BIOS. . . . .	16
<b>Chapter 4: BIOS Settings</b>	<b>17</b>
Accessing the BIOS menu . . . . .	17
Navigating the BIOS menu. . . . .	17
The Main Menu . . . . .	18
Advanced Settings. . . . .	19
Chipset Configuration. . . . .	28
Boot Configuration. . . . .	29
Security Settings . . . . .	31
Save & Exit . . . . .	32
<b>Appendix A: Programming Watchdog Timer</b>	<b>34</b>
<b>Appendix B: Setting up Console Redirections</b>	<b>35</b>
<b>Appendix C: Programming the LCM</b>	<b>36</b>
<b>Appendix D: Programming Generation 3 LAN Bypass</b>	<b>37</b>
<b>Appendix E: Installing Intel QuickAssist Software for Linux</b>	<b>38</b>
<b>Appendix F: Driver Installation</b>	<b>39</b>
Intel Chipset Driver Installation . . . . .	39
LAN Adapters Driver Installation. . . . .	40
On the Windows OS . . . . .	40
On Linux . . . . .	41
Intel Rapid Storage Technology Software Installation. . . . .	42
<b>Appendix G: Terms and Conditions</b>	<b>43</b>

## Chapter 1: Introduction

Thank you for choosing the FW-8893/FW-8893C. The FW-8893/FW-8893C is a 1U platform which features dual Intel Xeon E5-2600 coupled with cave creek PCH. It features many major advanced technologies as the following stated:

- 2nd Generation Intel Xeon E5-2600/E5-2600 v2 Processor family for the LGA 2011:

The motherboard supports up to 2 CPU configurations (and up to 8 cores per CPU) in the latest 2nd generation Intel E5-2600 processor in the LGA 2011 package. This new CPU also comes with the newest PCIe 3.0 bus standard.

- Intel Cave Creek/Coletto Creek Platform Controller Hub:

The built-in Intel QuickAssist technology on the Coletto Creek/Cave Creek chipset provides bulk data encryption/decryption using AES, 3DES or (A)RC4 algorithms and hash using MD5, SHA-1/2 and HMAC algorithms and pattern matching. The chipset will also support Intel Virtualization Technology.

- Quad-Channel DDR3 DIMM support:

The motherboard supports DDR3 memory that features quad-channel memory configurations in 16 DIMMs.

- 4 pairs of Lanner Generation 3 bypass

The system supports 4 pairs of Generation 3 bypass to allow continuous traffic flow even when the system hangs. We offer a comprehensive suite to implement this feature by programming. See appendix for more information.

Refer to the chart below for a summary of the system's specifications.

Note: For instructions on quick installation and acquiring the Intel® Communications Chipset 895x Series Software (Coletto Creek) and the Intel® Communications Chipset 89xx Series Software (Cave Creek), refer to the attached PDF file AV-ICE02 and AV-ICE01 respectively.

## System Specification

<b>Form Factor</b>		1U Rackmount
<b>Platform</b>	Processor Options	2x Intel® Xeon® E5-2600 series on LGA2011/E5-2600 v2 series on LGA2011
	Chipset	Intel® DH8920/8950
<b>BIOS</b>		AMI BIOS 64MB SPI Flash ROM
<b>System Memory</b>	Technology	Quad-channel DDR3 1066/1333/1600MHz RDIMM or UDIMM, Support ECC
	Max. Capacity	128GB
	Socket	16 x 240P DIMM
<b>OS Support</b>		Linux kernel 2.6 or above
<b>Storage</b>	HDD Bays	1 x 2.5" SATA HDD
	CompactFlash	1 x Type II CompactFlash
<b>Networking</b>	Ethernet Ports	14/10xGbE copper RJ45 ports and 6x10G SFP+
	Bypass	2 pairs Gen 3
	Controllers	1x Intel I347-AT4, 2x Intel I350-AM4, 3x Intel 82599ES
	Ethernet Modules	N/A
	Management Port	2 x GbE (RJ-45)
	Security Acceleration	Intel QuickAssist technology
<b>I/O Interface</b>	Reset Button	Software programmable reset button
	Console	1 x RJ45
	USB	2 x USB 2.0
	IPMI via OPMA slot	Optional
<b>Expansion</b>	PCIe	2 x PCI-E*16 through by ZD connector reserved for the custom model in 2U form factor
	PCI	N/A
<b>Cooling</b>	Processor	CPU heatsink with fan duct
	System	4x independent hot-swappable cooling fans with smart fan control
<b>Environmental Parameters</b>	Temperature, ambient operating / storage	0 ~ 40° C / -20~70° C
	Humidity (RH), ambient operating / ambient non-operating	5~90%, non-condensing/5~95%, non-condensing
<b>Miscellaneous</b>	LCD Module	128 x 64 Graphic LCM
	Watchdog	Yes
	Internal RTC with Li Battery	Yes



<b>Physical Dimensions</b>	Dimensions (WxHxD)	440 x 44 x 550 mm
	Weight	13 kg
<b>Power</b>	Type / Watts	1+1 ATX redundant powers 650W/each
	Input	AC 90~264V @47~63 Hz
<b>Approvals and Compliance</b>		CE (EMC), FCC Class A, RoHS
<b>Ordering Information</b>		
<b>FW-8893A</b>		MB-8893A + LCM + 7 key pad + 2 MGMT port, 12 x RJ-45 port, 6 x 10G SPF+
		MB-8893C + LCM + 7 key pad + 2 MGMT port + 8 x RJ-45 port, 6 x 10G SPF+


### Package Contents

Your package contains the following items:

- FW-8893 Network Security Platform
- 2 passive CPU heatsink
- 2 power cables
- 1 crossover Ethernet cable (1.8 meters)
- 1 straight-through Ethernet cable (1.8 meters)
- 1 RJ-45 to DB-9 female console cable
- Drivers and user's manual CD.



### Front Panel Features



#### F1 Power/Status/HDD LED

**Power:** If the LED is on it indicates that the system is powered on. If it is off, it indicates that the system is powered off.

**Status:** This LED is programmable. You could program it to display the operating status with the behavior like:

If the LED is green, it indicates that the system's operational state is normal. If it is red, it indicates that the system is malfunctioning.

**HDD:** If the LED blinks, it indicates data access activities; otherwise, it remains off.

#### F2 System Panel with keypad: LCD System Panel

The LCD System Panel can be programmed to display operating status and configuration information. For more details or sample programming code, please refer to the Drivers and User's manual CD.

#### F3 Console Port

By using suitable rollover cable or RJ-45 to DB-9 Female (Cisco console cable), you can connect to a computer terminal for diagnostic or configuration purpose. Terminal Configuration Parameters: 115200 baud, 8 data bits, no parity, 1 stop bit, no flow control.

#### F4 Two USB 2.0 Ports

It connects to any USB devices, for example, a flash drive.

#### F5 Management Port (LAN1 and LAN2 which are provided by Intel 82574L)

This FastEthernet port can be connected for configuration or troubleshooting purpose. Conformity with IPMI (Intelligent Platform Management Interface) can be implemented through OPMA on LAN1. LAN2 is also capable of Preboot eXecution Environment (PXE) to boot computers using a network interface. (This feature can be enabled or disabled in the BIOS; the default is disabled).



F6 13 GbE Ports (LAN3~LAN10 are provided by Intel i350 and LAN11~LAN14 (not for FW-8893C) are provided by Intel i347)

LINK/ACT (Yellow)	SPEED (Green/Amber)
<ul style="list-style-type: none"><li>On/Flashing: The port is linking and active in data transmission.</li></ul>	<ul style="list-style-type: none"><li>Amber: The connection speed is 1000Mbps.</li></ul>
<ul style="list-style-type: none"><li>Off: The port is not linking.</li></ul>	<ul style="list-style-type: none"><li>Green: The connection speed is 100Mbps</li></ul>
	<ul style="list-style-type: none"><li>Off: The connection speed is 10Mbps.</li></ul>

F7 10G SFP+ (provided by Intel 82599ES)

The Fibre Channel LEDs indicate the status of the Fibre Channel ports.

Two LEDs are used to indicate the state and speed of the operation of each Fibre Channel port. The left LED indicates the link state and the right LED indicates link activity


LED state	Link state
OFF	Non-link
ON	Link
ON	ACTIVE

LED state	Link activity
OFF	Non-link
ON	Link
BLINKING	Active in data transmission

With Intel i347 and i350, it equips with Intel Virtualization for Connectivity (VT-c) as part of the Intel Virtualization Technology suite to improve networking and I/O throughput on a virtualized system (you also need to turn on the CPU Virtualization in the BIOS menu). Moreover, 2 pair (**LAN7-LAN8**, **LAN9-LAN10** on the Ethernet module can be configured as LAN Bypass (Lanner Generation 3) when failure events occur (depending on the type of LAN modules). This feature can be implemented with a watch dog timer to enable it automatically. Refer to your User's Manual CD for a sample implementation of this feature.



### Rear Panel Features



R1 Hot Swappable System Fans (from left to right corresponding to the connector: FAN4, FAN3, FAN2, FAN1)

R2 Power-on Switch

It is a switch to turn on or off the power.

R3 Reset Button

The reset switch can be used to reboot the system without turning off the power. It can be programmed to act as a hardware or software reset. Refer to the User Manual and Driver CD for sample code.

R4 Power Supply Alarm Switch

When the alarm sounds (it indicates a power supply failure), switch off this button to turn off the alarm. Replace the failed power supply as soon as possible.

R5 Redundant Power Supply

The 650W redundant power supply is hot-swappable and can be withdrawn and replaced when the alarm sounds. The LED of the failed power supply will be turned off. To replace the failed power supply unit, unscrew the screw and press the latch to release the unit and pull it out.

## Chapter 2: Hardware Setup

### Preparing the Hardware Installation

To access some components and perform certain service procedures, you must perform the following procedures first.



**WARNING:** To reduce the risk of personal injury, electric shock, or damage to the equipment, remove the power cord to remove power from the server. The front panel Power On/Standby button does not completely shut off system power. Portions of the power supply and some internal circuitry remain active until AC power is removed.


1. Unpower the FW-8893 and remove the power cord.
2. Unscrew the 3 screws on left and right and two screws on the back of the top cover.
3. Slide the cover backwards and open the cover.



### Installing the System Memory

The motherboard supports DDR3 memory to meet the higher bandwidth requirements of the latest operating system and Internet applications. It comes with Quad-Channel DDR3 Dual Inline Memory Modules (DIMM) sockets (a total of 16 DIMMs for 2 CPUs).

1. Open the DIMM slot latches.
2. Install the DIMM.



#### Note:


1. The motherboards can support up to 128 GB memory capacity in maximum.
2. The system support dual CPU configuration. If you have only one CPU, populate the DIMMs close to the installed CPU socket
3. Since the system is capable of *Quad Channel* configuration, some installation guidelines have to be followed to enable Quad Channel mode: To insert 4 DIMMs on the system, insert DIMMs into the 4 slots with black latches nearest to the designated CPU socket (CPU socket No1 or No2). And use slots with white latches if more slots are required.
4. To activate Dual Channel instead of Quad Channel in the system, populate any 2 slots with black latches nearest to the designated CPU socket (CPU socket No1 or No2). And then use slot(s) with white latch that belongs to the same channel as the populated slot(s) for any additional DIMMs.
5. Starting from the board edge (same for both CPU socket No1 and No2), one pair of black and white-latched slots is configured as one channel.



### Installing a CompactFlash Card

FW-8893 provides one CompactFlash slot. Follow the procedures below for installing a CompactFlash card.

1. Align CompactFlash card and the card slot with the arrow pointing toward the connector.
2. Push the card to insert into the connector.




### CPU and the Heat Sink Installation


The FW-8893 sever system is powered by the MB-8893 sever board, which comes with two LGA2011 CPU sockets.

Follow the procedures below for installing a CPU

1. Remove the CPU socket cap.
2. Press the load lever and release it from the retention tab. There are two levers for each CPU socket. Follow the sequence as instructed on the right to release both of them.
3. Lift the load lever and then the plate.
4. Align the cut edge of the CPU and the notch on the socket. The CPU should fit perfectly into the socket. Note that the CPU fits in the socket in only one direction.
5. Close the plate and push the load lever to lock it back to the retention tab.
6. Put the heat sink on the installed CPU, match the screws with the screw holes in the board. Tighten each set of diagonally opposed screws at a time. It is easier this way to avoid the force of spring.
7. Place the heat sink cover on top of the installed heat sink and to fasten it with screws on the chassis.



6



### Note:


1. If you have only one CPU, install it on the left side (CPU socket No.1 with the front panel facing you). Failure to do so will result in boot failure. Note that the two ports farthest to the right will be disabled if only one CPU is installed.
2. To protect the CPU socket pins, retain the CPU cap when the CPU is not installed.


## Hard Disk Installation

The system support one 2.5" internal HDD installation.

Follow these steps to install a HDD:

1. Unscrew the 4 screws on the hard disk tray to take out the hard disk tray from the system.
2. Place hard disk on the hard disk tray and align the holes on the hard disk with the mounting holes on the tray.
3. Secure the hard disk with 4 mounting screws on the hard disk tray.
4. Connect the Serial-ATA power and data cables to the hard disk's power and data connectors respectively.
5. Fix the hard disk back to the system with the screws.
6. Plug the Serial-ATA cable to the Serial-ATA Connector on the main board.






## Chapter 3: Motherboard Information


### Block Diagram

The block diagram depicts the relationships among the interfaces or modules on the motherboard. Please refer to the following figure for your motherboard's layout design.




### Motherboard Layout

The motherboard layout shows the connectors and jumpers on the board. Refer to the following picture as a reference of the pin assignments and the internal connectors.




### Jumper Settings

**LCM\_1:** USB-type front LCD Message Display Module (LCM). It supports both text and graphic type of LCM.




Pin No.	Function	Pin No.	Function
1	P5V_USB4_L	2	P5V
3	USB4_SB_L_DN	4	
5	USB4_SB_L_DP	6	HDD_LED_N
7	GND	8	GND
9	NTXD2	10	NRXD2

### ATX1: 24-Pin ATX Power Connector



Pin No.	Function	Pin No.	Function
1	+3.3V	13	+3.3V
2	+3.3V	14	-12V
3	Ground	15	Ground
4	+5V	16	PSON-
5	Ground	17	Ground
6	+5V	18	Ground
7	Ground	19	Ground
8	Power Good	20	NC
9	Stand-By 5V	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	+3.3V	24	Ground


### ATX2, ATX3, ATX4, ATX5: 8-Pin ATX Power Connector



Pin No.	Function	Pin No.	Function
1	GND	2	12V
3	GND	4	12V
5	GND	6	12V
7	GND	8	12V

### SATA1: SATA Revision II Drive Connector

It is for connecting one 2.5" SATA harddisk to be served as your system's storage. The system's BIOS supports 2 modes of SATA configuration, i.e., IDE and AHCI. The chipset provides hardware support for Advanced Host Controller Interface (AHCI) which is a programming interface for SATA host controllers. AHCI provides advanced performance and usability enhancements with SATA such as Hot-Plug, no master/savle designation for SATA devices and native command queuing (NCQ).



Pin No.	Function
1	GND
2	TX_P
3	TX_M
4	GND
5	RX_M
6	RX_P
7	GND

**FAN1~6:** 5-Pin FAN Connector. The 4-pin connector is for connecting the CPU and system fans. These fans have smart features that can be automatically set to operate at certain speed according to the detected CPU or system temperatures. For more information, see **Smart Fan Mode Configuration** in *Chapter 4 BIOS Settings*.




Pin No.	Description
1	Ground
2	12V
3	RPM Sense
4	RPM Sense
5	PWM Status



# Chapter 3

## Motherboard Information

### CONN1: Power-on switch connector




Pin No.	Description
1	Ground
2	FP_SWIN_R

### CONN4: Reset switch connector




Pin No.	Description
1	Ground
2	Reset Signal

**USB3:** USB Connector for USB port #2 and #3. It is for connecting the USB module cable. It complies with USB2.0 and support up to 480 Mbps connection speed.




Pin No.	Description	Pin No.	Description
1	USB_VCC	2	USB_VCC
3	USB2-	4	USB3-
5	USB2+	6	USB3+
7	Ground	8	Ground
9	Ground	10	Ground

### USB4: Dual USB Connector



Pin No.	Description	Pin No.	Description
1	USB_VCC	5	USB_VCC
2	USB0-	6	USB1-
3	USB0+	7	USB1+
4	GND	8	GND

**VGAA1:** VGA Interface. with a 2x6 (2.54") pin header. It is for connecting the VGA interface cable. **Note the IPMI card (connector Reference NO. OPMA1) has to be present for this connector to work, i.e., the IPMI card provides VGA interface/signal.**



Pin No.	Function	Pin No.	Function
1	R	2	Ground
3	G	4	Ground
5	B	6	Ground
7	H-SYNC	8	Ground
9	V-SYNC	10	Ground
11	Detect-display Data	12	Detect-display CLOCK



**Note:** A 2x6 pin (2.0") header (J1) on the OPMA card is also provided as an VGA interface connector.

### CF2: CF Card Connector


Pin No.	Description	Pin No.	Description
1	GND	26	CD1-
2	DATA3	27	DATA11
3	DATA4	28	DATA12
4	DATA5	29	DATA13
5	DATA6	30	DATA14
6	DATA7	31	DATA15
7	CE1#	32	CE2#
8	A10	33	VS1#
9	OE#	34	IOR#
10	A9	35	IOW#
11	A8	36	WE#
12	A7	37	READY#
13	CFVCC3	38	CFVCC3
14	A6	39	CSEL
15	A5	40	VS2#
16	A4	41	RESET
17	A3	42	WAIT#
18	A2	43	INPACK#
19	A1	44	REG#
20	A0	45	DASP#
21	DATA0	46	DIAG#
22	DATA1	47	DATA8
23	DATA2	48	DATA9
24	WP	49	DATA10
25	CD2-	50	GND



# Chapter 3


## Motherboard Information

**COMB4: COM PORT Connector**



Pin No.	Description	Pin No.	Description
1	Data Carrier Detect (DCDB #)	6	Clear To Send (CTS#)
2	Data Set Ready (DSRB #)	7	Data Terminal Ready (DTRB #)
3	Receive Data (RXDB)	8	Ring Indicator (RIB #)
4	Request To Send (RTSB #)	9	Ground
5	Transmit Data (TXDB)	10	KEY

**COMB5: Bypass function programmer**



Pin No.	Description	Pin No.	Description
1	NC	6	NXP_CTS_N
2	NC	7	NC
3	NXP_RXD	8	NC
4	NXP_RTS_N	9	GND
5	NXP_TXD	10	P3V3_SB

### DIMM Sockets:

Since the system is capable of *Quad Channel* configuration, some installation guidelines have to be followed to enable Quad Channel mode. To insert 4 DIMMs on the system, insert DIMMS into the 4 black slots with black latches nearest to the designated CPU socket (CPU socket No1 or No2). And then use slots with white latches if more slots are required.




**Note:**

- To activate Dual Channel instead of Quad Channel in the system, populate any 2 slots with black latches nearest to the designated CPU socket (CPU socket No1 or No2). And then use slot(s) with white latch that belongs to the same channel as the populated slots for any additional DIMMs.
- Starting from the board edge (same for both CPU socket No1 and No2), one pair of black and white-latched slots is configured as one channel.

**CPU Socket NO.1 and CPU Socket NO. 2:** When using only one CPU, install the CPU on the *socket NO.1* or the system will not function.

**OPMA1:** OPMA Connector. The OPMA connector is for connecting the OPMA card. When the OPMA card is connected, the management port will comply with the Intelligent Platform Management Interface (IPMI) standard.



**Note:**

1. The management port on the front panel will not pass through when the IPMI card is present (board reference NO. OPMA1); The management port and IPMI share the same output port (the LAN1 port on the front panel). Use the jumper J110 to switch between these two signals.
2. A simple workaround: To have both VGA and Management function(non- IPMI compliant) connections, take out the jumper block on J110.

**Reset Function Selection (J91):** A reset switch to switch between hardware and software reset function for the front panel reset button. A hardware reset function will reset the whole system while a software reset function will reset the designated software to its default value.



Pin No.	Description
1-2	Hardware Reset
2-3	Software Reset

**Clear CMOS Jumper(J29):** Use this jumper to reset the BIOS setting to its factory default.



Pin No.	Description
1-2	Normal (default)
2-3	Clear CMOS

**IPMI and Management Port Switch (J110):** A switch to switch the output signal between management and OPMA1 since they share the same access port (the management port on the front panel). To let the management signal pass through instead of the OPMA signal (refer to jumper OPMA1), take out this jumper. In this way, you could have both VGA and Management connections (non-IPMI).

Pin No.	Description
Short1-2	IPMI signal
Open	Management signal pass through



### Chapter 4: BIOS Settings

---

#### Updating the BIOS

The Basic Input/Output System (BIOS) can be updated using the designated Flash Utility. To obtain the utility, please contact us either through the sales rep or technical support.



## Chapter 4: BIOS Settings

### Accessing the BIOS menu

When you are installing a motherboard or when the system prompts “Run Setup” during start-up, you will use the BIOS Setup program to configure the system, . This section explains how to configure your system using this program.

Even if you are not prompted to enter the BIOS Setup program when you are installing a motherboard, you can still change the configuration of your computer later on with this program. For example, you may want to enable the security password feature or change the power management settings. This requires you to reconfigure your system by using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM .

When you start up the computer, the system provides you with the opportunity to run this program. Press <Delete> during the Power-On-Self-Test (POST) to enter the Setup utility (There are a few cases that other keys may be used, such as <F1>, <F2>, and so forth.); otherwise, POST continues with its test routines.

If you wish to enter Setup after POST, restart the system by pressing <Ctrl+Alt+Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on. Do this last option only if the first two failed.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.



**Note:** This manual describes the standard look of the setup screen. There may be some instances in which the motherboard features can vary from one to another due to customization. This means that some of the options described in this manual may not match that of your motherboard’s AMIBIOS.

### Navigating the BIOS menu

The BIOS setup utility uses a key-based navigation system called hot keys. Most of the BIOS setup utility hot keys can be used at any time during the setup navigation process.

These keys include <F1>, <Enter>, <ESC>, <Arrow> keys,



Keys	Description
-><- Left/Right	The Left and Right <Arrow> keys allow you to select an setup screen. For example: Main screen, Advanced screen, Boot screen, and so on.
Up/Down	The Up and Down <Arrow> keys allow you to select an setup item or sub-screen.
+ - Plus/Minuss	The Plus and Minus <Arrow> keys allow you to change the field value of a particular setup item. For example: Date and Time.
Tab	The <Tab> key allows you to select setup fields.




### The Main Menu

The main BIOS setup menu is the first screen that you can navigate. Each main BIOS setup menu option is described in this chapter.


The Main BIOS setup menu screen has two main frames. The left frame displays all the options that can be configured. "Grayed-out" options are configured parameters and cannot be modified. On the other hand, Options in blue can be modified.

The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.



### System Language

Use this item to choose the BIOS language.



### System Time/System Date

Use this option to change the system time and date. Highlight System Time or System Date using the <Arrow> keys. Enter new values through the keyboard. Press the <Tab> key or the <Arrow> keys to move between fields. The date must be entered in MM/DD/YY format. The time is entered in HH:MM:SS format.




### Advanced Settings

#### Restore AC Power Loss


This option lets you set the state of the system when it has just recovered from a power outage.

Option	Description
Power Off	When setting to Power Off, the system goes into "off state" after an AC power interruption.
Power On	When setting to Power on, the system turns on automatically after a power interruption
Last State	When setting to Last State, the system goes into whatever the state was before the power interruption.



#### LAN PXE Boot

The Preboot eXecution Environment (PXE) allows you to boot computers using a network interface independently of data storage devices (like hard disks) or installed operating systems. Enable or disable this function on management port 2 (LAN 2)






### CPU Configuration Settings

You can use this menu to enable/disable certain functions of your CPU. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. A description of the selected item appears on the right side of the screen. The settings are described below.

### CPU Information

You can use this screen to view the basic information and capabilities of your CPU. For instance, the clock rate and L1 to L3 cache sizes are displayed here.

Item	Selection
Intel Hyper-Threading	The Intel Hyper-Threading Technology allows a hyper-threading processor to appear as two logical processors to the operating system, allowing the operating system to schedule two threads or processes simultaneously. Select to enable or disable this feature.
Active Processor Core	Select the number of processor cores to be active in each processor package.
Limit CPUID Maximum	Allows legacy operating systems to boot even without support CPUs with extended CPUID functions. Select to enable or disable this function
Execute Disable Bit	Select to enable or disable the No-Execution Page Protection Technology.
Hardware Prefetcher	The processor has a hardware prefetcher that automatically prefetches data and instructions from the memory into the Level 2 cache that are likely to be required in the near future. This reduces the latency associated with memory reads. When enabled, the processor's hardware prefetcher will be enabled and allowed to automatically prefetch data and code for the processor. When disabled, the processor's hardware prefetcher will be disabled.
Adjacent Cache Line P	Select to enable or disable prefetching of adjacent line
DCU Streamer Prefetch	Enable prefetch of next L1 Data Line based on multiple loads in the same cache line.
DCU IP Prefetcher	Enable prefetch of next L1 line based on sequential load history.
Intel Virtualization	The Intel VT is a hardware-assisted virtualization. This processor supports Intel Virtualization. Enable or disable this feature.



### SATA Configuration

You can use this menu to configure SATA controller and SATA ports.




### SATA Mode Selection

The system supports advanced SATA features such as AHCI mode.

Item	Selection
IDE Mode	Set to IDE mode when you want to use the Serial-ATA hard disk drives as Parallel ATA physical storage devices.
AHCI Mode	Set to AHCI mode when you want the SATA hard disk drives to use the AHCI (Advanced Host Controller Interface). The AHCI allows the onboard storage driver to enable advanced SATA features that increases storage performance or workloads where multiple simultaneous read/write requests are outstanding, most often occurring in server-type applications (native command queuing). It also facilitates hot swapping.
Disable	Disable the SATA controller.

### Staggered Spin-up


Spin-up can be employed to prevent the excessive power-consumption of spin-up from resulting in a power shortage in computers with multiple hard drives. Staggered spin-up typically starts one drive at a time, either waiting for the drive to signal it is ready or allowing a predefined period of time to pass before starting the next drive. Select to enable or disable this feature.



### Serial ATA Port 0/1

Use this menu to configure specific SATA Port for all ports on the system.

Option	Description
Hot Plug	The AHCI of SATA provides hot plug capability to allow drives to be added or removed with the PC running.



### USB Configuration Settings

You can use this screen to select options for the USB Configuration. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. The settings are described on the following pages.

### Legacy USB Support




This option enable or disable the support for USB devices on legacy operating systems (OS), e.g., Windows ME/98/NT, and MS-DOS. Normally if this option is not enabled, any attached USB mouse or USB keyboard will not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can be used on the system even when there is no USB drivers loaded on it.

Option	Description
Auto	Allow the system to detect the presence of USB devices at startup. If detected, the USB controller legacy mode is enabled. If it is not detected, the USB controller legacy mode is disabled.
Enabled	Enable the support for USB devices on legacy operating system
Disabled	Disable this function.

### EHCI Hand-Off

It allows you to enable support for operating systems which do not have the Enhanced Host Controller Interface hand-off (EHCI hand-off) feature for USB devices.

Option	Description
Enabled	Enable this feature
Disabled	Disable this feature



### USB Mass Storage Driver

It allows the system to detect the USB mass storage. Enable this option to let system detect the presence of USB mass storage.

Option	Description
Enabled	Enable this feature
Disabled	Disable this feature

### Port 60/64 Emulation



This BIOS feature allows you to enable emulation of I/O ports 64h and 60h so that there is full PS/2 legacy support for USB keyboards and mice. It is also useful in providing USB keyboard and mouse support in Windows NT which does not natively support USB.

Option	Description
Enable	The BIOS will emulate I/O ports 64h and 60h for the USB keyboard and mouse. This enables PS/2 functionality like keyboard lock, password setting and code selection.
Disable	The BIOS will not emulate I/O ports 64h and 60h for the USB keyboard and mouse. They will not have PS/2 functionality.

### USB Hardware Delays a

The menu sets delay time for USB operations.

Item	Description
USB transfer time-out	set transfers to an endpoint to complete within a specific time. <ul style="list-style-type: none"> <li>If set to zero, transfers will not time out because the host controller will not cancel the transfer. In this case, the transfer waits indefinitely until it is manually canceled or the transfer completes normally.</li> <li>If set to a nonzero value (time-out interval), the host controller starts a timer when it receives the transfer request. When the timer exceeds the set time-out interval, the request is canceled.</li> </ul>
Device reset time-out	This option sets the reset timing for the USB Mass Storage to be initialized. When set to 10 Sec, the BIOS will wait for up to 30 seconds for the USB flash drive to initialize.
Device power-up delay	This option sets the power-up timing for the USB Mass Storage to be initialized.



### PC Health Status

This menu shows the hardware monitor configuration settings. Select an item then press <Enter> to display the configuration options.

### CPU0/CPU1/System Temp1/System Temp2 Temperature


The onboard hardware monitor automatically detects and displays the CPU and motherboard temperatures.

### FAN1B/FAN2B/FAN3B/FAN4B Speed

The onboard hardware monitor automatically detects and displays the CPU , chassis and system fan speeds in rotations per minute (RPM). If the fan is not connected to the motherboard, it displays N/A.

### CPU Voltage, 3V voltage, 5V voltage voltage


The onboard hardware monitor automatically detects the voltage output through the onboard voltage regulators.



### Smart Fan Mode Configuration

It allows you to configure the smart fan feature. You can manually turn on the CPU fan or enable the smart fan feature. And the CPU fan can be turned on automatically and operate at a slower or faster speed according to a preset temperature and duty cycle values. Refer to *Motherboard Layout* on Chapter 3 *Block Diagram* for CPU and system fan connectors. Note that all fans are configured the same with a uniform configuration.

Item	Selection
Manual Mode	Manually set the fan speed from 0 (slowest) to 255 (fastest)
Smart Fan Mode	This presets the target CPU and system temperatures at which the system fan will start running according to a preset duty cycle %. 40(°C).....5500 rpm 60(°C).....10300 rpm 70(°C).....12000 rpm 78(°C).....13000 rpm 83(°C).....full speed





### Cave Creek Chipset Configuration

In this screen, you will be able to modify the IRQ address of the serial ports which are provided by the Cave Creek chip.

### Serial Port 0/1 Configuration

This option specifies the base I/O port address and Interrupt Request address of serial port 0 and 1.

item	Selection
Enabled/ Disabled	Set this value to prevent the serial port from accessing any system resources. When this option is set to Disabled, the serial port physically becomes unavailable.
Change Settings	Selects the serial port base address and IRQ for the interrupt address.





### Console Redirection

Use this menu to set the settings for BIOS remote access feature.

Item	Selection
Console Redirection	Enable or disable BIOS through remote access
Console Redirection Settings	Enter to view more options

### COM0/COM1 Console Redirection Settings


Item	Selection
Terminal Type	Sets the connection terminal type
Bits per second, Data bits, Parity, Stop Bits, Flow Control	Sets the terminal connection parameters such as the baud rate, parity check mechanism, etc.



### Chipset Configuration


#### DIMM Information

The DIMM information displays the installed DIMM information



### Boot Configuration


Select the Boot tab from the setup screen to enter the Boot BIOS Setup screen. You can select any of the items in the left frame of the screen, such as Boot Device Priority, to go to the sub menu for that item. You can display an Boot BIOS Setup option by highlighting it using the <Arrow> keys. Select an item on the Boot Setup screen to access the sub menus for the following described functions.



### Boot Settings Configuration

In this screen, you will be able to configure the boot procedures and the related elements.

Items	Options
Setup Prompt Timeout	Specify the number of seconds for the boot setup prompt to wait for user's intervention during the POST.
Bootup Num-Lock State	This option allows you to enable or disable the function of the NumLock key.
Quiet Boot	Enabling this item allows the BIOS to suppress the message displayed during the POST.
Fast Boot	Select enabled to accelerate the boot speed and disabled to go back to normal boot.  The following items appear when you set fast boot to "Enabled".  VGA Support: Auto- only legacy optional ROM with legacy OS will be installed but the logo will not be shown when booting.  EFI - the EFI driver will be installed along with the EFI OS.



Items	Options
<p><b>Fast Boot</b></p>	<p>USB Support:</p> <p>Disabled- All USB devices will not be available until OS boot up for a fastest POST time.</p> <p>Full Initialization- All USB devices will be available during POST. This process will extend the POST time.</p> <p>Partial Initialization- For a faster POST time, only the USB ports with keyboard and mouse connections will be detected.</p> <p>PS2 Devices Support:</p> <p>Auto- For a faster POST time, PS/2 devices will only be available when the system boots up or rebooted when the PS/2 devices have not been reconnected or changes.</p> <p>Disabled- all PS/2 devices will not be available until your computer enters the operating system.</p> <p>Full initialization- PS/2 devices will not be available and BIOS setup program will not be accessible via PS/2 devices.</p> <p>Network Stack Driver Support-:</p> <p>Enabled/Disabled: Select enabled/disabled to load/not load the network stack driver during POST.</p>
<p><b>Boot Option Priorities</b></p>	<p>Use this screen to specify the order in which the system checks for the device to boot from.</p>



### Security Settings

Select Security Setup from the Setup main BIOS setup menu. All Security Setup options, such as password protection and virus protection, are described in this section. To access the sub menu for the following items, select the item and press <Enter>:

#### Administrator Password

If you have set an administrator password, you should enter the administrator password for accessing the system. Otherwise, you will only be able to see or change selected fields in the BIOS setup program.

#### User Password

If you have set a user password, you must enter the user password for accessing the system.


To set an Administrator/User password:

1. Select the option item and press Enter.
2. From the Create New Password box, key in a password, then press enter.
3. Confirm the password when prompted.

To change an administrator password:

1. Select the option item and press Enter.
2. From the Enter Current Password box, key in the current password, then press enter.
3. From the Create New Password box, key in a new password, then press Enter.
4. Confirm the password when prompted.


To clear the administrator password, follow the same steps as in changing an administrator password, then press Enter when prompted to create/confirm the password.



### Save & Exit

Select the Exit tab from the setup screen to enter the Exit BIOS Setup screen. You can display an Exit BIOS Setup option by highlighting it using the <Arrow> keys. The following table lists the options in this menu.

Item	Options
Save Changes and Exit	When you have completed the system configuration changes, select this option to leave setup. The system will decide to either reset or continue on booting process depending on whether a reboot will be necessary for the changes to take effect.
Discard Changes and Exit	This option allows you to discard the selections you made and restore the previously saved values. After selecting this option, a confirmation appears. Select Yes to discard any changes and load the previously saved values. You will then exit the program and continue on the booting process.
Save Changes and Reset	When you have completed the system configuration changes, select this option to leave setup and reboot the computer so the new system configuration parameters can take effect.
Discard Changes and Reset	This option allows you to discard the selections you made and restore the previously saved values. After selecting this option, a confirmation appears. Select Yes to discard any changes and load the previously saved values. The system will then reset.
Save Changes	Save your changes
Discard Changes	Discard changes
Restore Defaults	Restore to factory defaults
Save as User Defaults	Save all of your changes as an user default setting.
Restore User Defaults	Loads your saved user default setting.



Item	Options
Boot Override	This section of the Boot Menu allows booting from a specific device immediately. Therefore you should see an entry for all bootable devices.
Launch EFI Shell from filesystem device	This option allows you to attempt to launch the EFI Shell application (shellx64.efi) from one of the available filesystem devices.



### Appendix A: Programming Watchdog Timer

---

A watchdog timer is a piece of hardware that can be used to automatically detect system anomalies and reset the processor in case there are any problems. Generally speaking, a watchdog timer is based on a counter that counts down from an initial value to zero. The software selects the counter's initial value and periodically restarts it. Should the counter reach zero before the software restarts it, the software is presumed to be malfunctioning and the processor's reset signal is asserted. Thus, the processor will be restarted as if a human operator had cycled the power.

For sample watchdog code, see *watchdog* folder on the *Driver and Manual CD*



To execute the sample code: enter the number of seconds to start count down before the system can be reset. Press start to start the counter and stop to stop the counter..

`Dwd_tst --swt xxx` (Set Watchdog Timer 1-255 seconds)

`wd_tst[*] --start` (Start Watchdog Timer)

`wd_tst --stop` (Stop Watchdog Timer)

For sample watchdog code, see *watchdog* folder on the *Driver and Manual CD*



### Appendix B: Setting up Console Redirections

---

Console redirection lets you monitor and configure a system from a remote terminal computer by re-directing keyboard input and text output through the serial port. The following steps illustrate how to use this feature. The BIOS of the system allows the redirection of console I/O to a serial port. With this configured, you can remotely access the entire boot sequence through a console port.

1. Connect one end of the console cable to console port of the system and the other end to serial port of the remote client system.
2. Configure the following settings in the BIOS Setup menu:  
  
BIOS > Advanced > Remote Access Configuration > Serial Port Mode > [115200, 8, n, 1]
3. Configure Console Redirection on the client system. The following illustration is an example on Windows platform:
  - a. A. Click the start button, point to Programs > Accessories > Communications and select Hyper Terminal.
  - b. B. Enter any name for the new connection and select any icon.
  - c. Click OK.
  - d. From the "Connect to". Pull-down menu, select the appropriate Com port on the client system and click OK.
  - e. Select 115200 for the Baud Rate, None. for Flow control, 8 for the Data Bit, None for Parity Check, and 1 for the Stop Bit.



### Appendix C: Programming the LCM

The LCD panel module (LCM) is designed to provide real-time operating status and configuration information for the system. For sample LCM code, see *LCM* folder on the *Driver and Manual CD*. The driver and the program library can also be found in the folder.

The system support USB LCM. The LCM connects to the motherboard's USB LCM port.

#### Jumper Selection for USB and Serial Text or Graphic-based LCM

Text LCM	1 1 0	J6	
		J7	
		J8	
Graphic LCM	1 1 1	J6	
		J7	
		J8	

#### Build

To build program source code on Linux platform, use the following steps as a guideline:

1. Extract source file:

```
#tar -xzvf lanner-serial-usb-lcm-version.tgz
```

2. Change directory to the extracted folder

```
#cd lanner-serial-usb-lcm-vx
```

3. Type make to build source code:

```
#make
```

After compilation, the executable programs (*usb\_disp*, *usb\_key*, *ser\_disp*, *ser\_key*) where *disp* denotes the control of display and *key* denotes the keypad input function and *usb* and *ser* denote USB and serial interfaces respectively will appear in the program's folder.



**Note:** The OS supported by Lanner LCM function include platforms based on Linux Kernel series 2.4.x and Linux Kernel series 2.6.x.

#### Install

```
#mknod /dev/usb/hiddev0 c 180 96
```



#### Note:

1. The OS supported by Lanner LCM function include platforms based on Linux Kernel series 2.4.x and Linux Kernel series 2.6.x, FreeBSD 8.0, and DOS.
2. For information on installation on platforms other than Linux, see `\lanner-serial-usb-lcm-v0.5\README` and `\lanner-serial-usb-lcm-v0.5\dos-example\README`

#### Execution

```
# ./ser_disp or ./usb_disp
```

Options:

```
[-l] | [-o XXXXX] | [ [-b YYYY] | [-f ttyS_No] | [-d filename] |
```

```
[-g filename] | [-c cmd] | [-0 arg0] [-1 arg1]... [-h]
```

[-l]: Identify LCM information and get flash setting

[-o XXXXX]: to override default baud rate

valid values are: 9600, 19200, 38400, 57600, 115200

[-b YYYY]: to change the baud rate

valid values are: 9600, 19200, 115200

[-f ttyS\_No]: assign the keypad device used as ttySNO

[-d filename]: to display the specified file on Text LCD

[-g filename]: to display the specified file on Graphic

LCD

[-0 arg0]: data[0]

[-1 arg1]: data[1]

[-2 arg2]: data[2]

[-3 arg3]: data[3]

[-4 arg4]: data[4]

[-v]: be verbose

[-h]: this help

```
#./ser_key or ./usb_key
```

The keypad function test program will not detect the keypad device; therefore, you should assign it with the [-f] option (the default is `/dev/ttyS0` or `/dev/usb/hiddev0`)



### Appendix D: Programming Generation 3 LAN Bypass

---

The bypass function is used to link two independent Ethernet ports when the system crashes or powers off. This means if your system is equipped with a LAN Bypass function, a condition in your system will not interrupt your network traffic. Different from the previous two generations (Gen1 and Gen2), the Lanner Bypass Gen 3 employs a programming method to control the bypass function by software. There are typically two communication status for the bypass function, one is "Normal" and another is "Bypass" status. Furthermore, the Lanner Bypass software is capable to control the bypass status in the following 3 instances.

1. When the system powers off, it can be forced to enable the LAN Bypass function .
2. When the system is in the just-on state which is a brief moment when it powers up .
3. When the system is running

Please refer to the LAN\_Bypass\_Watchdog folder on the Driver and Manual CD.

And the Lanner bypass possess the following features:

1. Communication through SMBUS (I2C)
2. Independent bypass status control for each pair up to a total of 4 pairs
3. Lanner Bypass Modules can bypass systems Ethernet ports on a host system during three instances: Just-on (Just-on is the brief moment when the internal power supply turns on and booting process starts), system off, or upon software request (during run-time).
4. Software programmable bypass or normal mode
5. Software programmable timer interval:
  - JUST-ON watchdog timer, used during JUST-ON, has timer setting of 5~1275 seconds of timer interval.
  - Run-Time watchdog timer, used during run-time, has setting of 1~255 seconds of timer interval.
6. Multiple Watchdog Timers:
  - Two for run-time: It is designed to give you a more variety of controls of the bypass on port basis. By using dedicated watchdogs for different pairs of bypass, you have the flexibility to manage the bypass status for them differently.
  - One for just-on: It is designed to give you the precise control of the bypass during this phase. You can use

this timer to delay enabling the bypass in just-on state.

For sample LAN bypass code and the Bypass Manual, see the LAN\_Bypass folder on the Driver and Manual CD or the Lanner Assist Website at <http://www.lannerinc.com/support/download-center>. And browse the support >download center, look for Lanner LAN Bypass Module Manual in the Accessories folder under User Manual category. You need to login to obtain the download materials.

For a description of the physical LAN ports equipped with this function, refer to *Front Panel Features* in *Chapter 1 Introduction*.



## Appendix E: Installing Intel QuickAssist Software for Linux

---

The FW-8893/8893C platform incorporates Intel QuickAssist Technology, which includes acceleration modules that are accessed via Intel QuickAssist software. The Intel quickAssist software also enables the acceleration modules to be easily accessed by open source software such as OpenSSL. The Intel QuickAssist Technology features acceleration to the following crypto functions:

- Symmetric Cryptographic Functions
  - Cipher Operations
  - Hash/Authenticate Operation
  - Cipher-Hash Combined Operation
  - Key Derivation Operation
- Public Key Functions
  - RSA Operation
  - Diffie-Helman Operation
  - Digital Signature Standard Operation
  - Key Derivation Operation
  - Elliptic Curve Cryptography: ECDSA\* and ECDH\*
- Compression
  - Deflate, Stateless, Dynamic

We provide an abstract version of the *Intel® Communications Chipset 8925 to 8955 Series Software for Linux and Getting Started Guide (No. 523128)* and *Intel® Communications Chipset 89xx Series Software for Linux Getting Started Guide (No. 440005)*. In this abstract version of Getting Started guide, it illustrates how to quickly get up and running with Fedora and **Intel® Communications Chipset 89xx (and 895x) Series Software package**. Refer to the attached PDF file for more information.



## Appendix F: Driver Installation

### Intel Chipset Driver Installation

This section provides the instructions on how to install Intel® chipset drivers.

The Intel Chipset Device Software installs the Windows\* INF files. The INF files inform the operating system how to properly configure the chipset for specific functionality, such as AGP, USB, Core PCI, and ISAPNP services.

To install the Intel® Chipset driver on a Windows Operating System:

1. Restart the computer, and then log on with Administrator privileges.
2. Insert the Drivers and User's Manual CD to the USB-optical drive.
3. Browse the contents of the support CD to locate the file `infinst_autol.exe` from the \Driver folder. Double-click the Executable file.
4. The program starts by extracting the file. Click Next to continue the installation process.
5. Click **Next** when the Intel® Chipset InstallShield Wizard window appears.



6. Click Next when the Readme File Information screen appears.



7. Click Yes when the Software License Agreement screen appears.



8. Click Finish when the Setup Complete screen appears.




### LAN Adapters Driver Installation

This section provides the instructions on how to install Intel® Gigabit LAN adapter drivers.

#### On the Windows OS

To install the Intel® Gigabit LAN controller driver on a Windows Operating System:


1. Restart the computer, and then log on with Administrator privileges.
2. Insert the Drivers and User's Manual CD to the USB-optical drive.
3. Browse the contents of the support CD to locate the file PRO2KXP.EXE from the \Driver\LAN folder. Double-click the Executable file.
4. The program starts by extracting the file. Click Next to continue the installation process.
5. Click **Next** when the Intel® PRO Network Connections –InstallShield Wizard window appears.



6. Select the "I accept the terms in the license agreement" and then click Next.



7. Select the programs that you wish to install. Make sure that you have selected the drivers.



8. Click Next and then **Install** to proceed the installation.
9. Click **Finish** to close the installation program.

To verify the LAN controller driver installation, do the following steps:

1. Right-click on the My Computer icon, and then select Properties from the menu.

Click the Hardware tab, then click the Device Manager button.

Click the + sign next to the Network adapters, then the Intel Pro/1000 [.....] adapter should be listed.



Note: The system uses Intel 82574L, Intel I347-AT4, Intel I350-AM4, Intel 82599ES Ethernet controllers, you could obtain the latest drivers at the Intel download center:

<http://downloadcenter.intel.com/>

You could also use the web based utility to detect the needed drivers automatically by visiting the following website:

<http://www.intel.com/support/network/detect.htm>



### On Linux

Follow these instructions when installing the Intel® LAN controller base driver for the in Red Hat® and Linux operating system.

1. Insert the motherboard/system support CD to the optical drive and mount the optional drive in the Linux platform.
2. Copy the base driver tar file from the motherboard/system support CD to the directory of your local hard disk. The Intel® LAN driver for Linux OS is located in the following directory:

`\Driver\LAN_Driver\PRO1000\LINUX`. The name format of driver file is "e1000-<Version>.tar.gz". For example: the file name of driver version 7.0.38 is "e1000-7.0.38.tar.gz".

3. Untar/unzip the archive, where <x.x.x> is the version number for the driver tar file:

```
tar xzf e1000-<x.x.x>.tar.gz
```

4. Change to the driver src directory on your system, where <x.x.x> is the version number for the driver tar:

```
cd e1000-<x.x.x>/src/
```

5. Compile the driver module by typing the following command:

```
make install
```

6. The binary will be installed as:

```
/lib/modules/<kernel_version>/kernel/drivers/net/  
e1000.o
```

The install locations listed above are the default locations. They might not be correct for certain Linux distributions.

7. Load the module using either the `insmod` or `modprobe` command:

```
modprobe igb
```

```
insmod igb
```

Note that for 2.6 kernels the `insmod` command can be used if the full path to the driver module is specified. For example:

```
insmod /lib/modules/<KERNEL_VERSION>/kernel/  
drivers/net/igb/igb.ko
```

With 2.6 based kernels also make sure that older `igb` drivers are removed from the kernel, before loading the new module:

```
rmmod igb; modprobe igb
```

8. Assign an IP address to the interface by entering the following, where <x> is the interface number:

```
ifconfig eth<x> <IP_address>
```

9. Verify that the interface works. Enter the following, where <IP\_address> is the IP address for another machine on the same subnet as the interface that is being tested:

```
ping <IP_address>
```



Note: The system uses Intel 82574L, Intel I347-AT4, Intel I350-AM4, Intel 82599ES Ethernet controllers, you could obtain the latest drivers at the Intel download center:  
<http://downloadcenter.intel.com/>



### Intel Rapid Storage Technology Software Installation

1. Insert the Drivers and User's Manual CD to the optical drive. Or you can download this software from Intel website too.
2. Browse the contents of the support CD under the directory: \Driver\ for RAID software.
3. Follow the on-screen instructions to install the software.



4. Restart the computer. You will find the "Intel Rapid Storage Technology" icon on the Windows task bar.



### Appendix G: Terms and Conditions

---

#### Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after service freight charges for goods returned to the user.
3. The buyer will pay for repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service," RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:

Improper or inadequate maintenance by the customer  
Unauthorized modification, misuse, or reversed engineering of the product  
Operation outside of the environmental specifications for the product.

#### RMA Service

Requesting a RMA#

6. To obtain a RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
7. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
8. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
9. Mark the RMA# clearly on the box.



**Note:** Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.

# Appendix G

## Terms and Conditions

### RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

<b>RMA No:</b>		Reasons to Return: <input type="checkbox"/> Repair(Please include failure details)	
		<input type="checkbox"/> Testing Purpose	
Company:		Contact Person:	
Phone No.		Purchased Date:	
Fax No.:		Applied Date:	
Return Shipping Address: _____			
Shipping by: <input type="checkbox"/> Air Freight <input type="checkbox"/> Sea <input type="checkbox"/> Express _____			
<input type="checkbox"/> Others: _____			
Item	Model Name	Serial Number	Configuration

Item	Problem Code	Failure Status

\*Problem Code:

- |                        |                              |                    |                          |
|------------------------|------------------------------|--------------------|--------------------------|
| 01: D.O.A.             | 07: BIOS Problem             | 13: SCSI           | 19: DIO                  |
| 02: Second Time R.M.A. | 08: Keyboard Controller Fail | 14: LPT Port       | 20: Buzzer               |
| 03: CMOS Data Lost     | 09: Cache RMA Problem        | 15: PS2            | 21: Shut Down            |
| 04: FDC Fail           | 10: Memory Socket Bad        | 16: LAN            | 22: Panel Fail           |
| 05: HDC Fail           | 11: Hang Up Software         | 17: COM Port       | 23: CRT Fail             |
| 06: Bad Slot           | 12: Out Look Damage          | 18: Watchdog Timer | 24: Others (Pls specify) |

**Request Party**

**Confirmed By Supplier**

\_\_\_\_\_  
Authorized Signature / Date

\_\_\_\_\_  
Authorized Signature / Date

